

tediselmedical

ARES

INSTALLATION MANUAL



CE 0197

tediselmedical.com

Content

1.	Manufacturer.....	6
2.	Security information.....	6
2.1.	Injury risk warnings.....	6
2.2.	Warnings of risk of damage	6
2.3.	Additional symbols used in the safety instructions.....	7
2.4.	Indication of additional information.....	7
2.5.	Proper use of oxygen.....	7
2.5.1.	Oxygen explosion.....	7
2.5.2.	fire hazard	8
2.6.	Patient environment.....	8
2.7.	Combination with products from other manufacturers.....	8
3.	Risks.....	9
3.1.	Gas explosion	9
3.2.	Risk of device malfunction	9
3.3.	Risk of patient contamination and infection.....	9
3.4.	Fire risk.....	9
3.5.	Danger of electric shock.....	10
3.6.	Risk of collision	10
3.7.	Risk of system crash due to overload	10
3.8.	Risk of system crash due to poor installation	10
4.	Symbols used	11
5.	Installation requirements	13
5.1.	Equipment required for installation	13
5.2.	Training	14
6.	Installation and connection	14
6.1.	Installation references.....	14
6.2.	Installation references. Accessories. Lighting, indicators.....	37
6.3.	Additional instructions.....	41
6.4.	Loading data.....	41
6.4.1.	CEILING FIXED ARES, ARES ROTATION	42
6.4.2.	ARES AIR	42
6.4.3.	ARES AIRPLUS AND ARES FRICTION	43

6.4.4.	ARES AND ARES INVERTED	43
6.4.5.	ARES XL.....	44
6.4.6.	ARES XXL.....	45
6.4.7.	ARES MOTOR, ARES MOTOR XL, ARES MOTOR XXL.....	46
6.4.8.	ARES MOTOR AIRPLUS, ARES MOTOR FRICTION	47
6.4.9.	ARES SPRING AIRPLUS, ARES SPRING FRICTION	48
6.4.10.	ARES SPRING E-BRAKE.....	48
6.4.11.	Service head and accessories	49
6.5.	Mounting of threaded bolts on the interface plate	50
6.5.1.	Installation without false ceiling.....	50
6.5.1.1.	Installation without false ceiling for CEILING FIXED ARES.....	52
6.5.2.	Installation with false ceiling	53
6.5.2.1.	Installation with false ceiling for CEILING FIXED ARES	56
6.5.3.	Mounting of interface plate on the false ceiling bracket.....	57
6.6.	Pre-assembly: Ceiling tube (included), drop arm and drop tube	59
6.6.1.	Description of components	59
6.6.2.	Ceiling tube mounting.....	63
6.6.2.1.	Mounting of ceiling tube for CEILING FIXED ARES	64
6.6.3.	Mounting tension release mechanism on the ceiling tube.....	65
6.6.4.	Roof tube earthing cable assembly.....	66
6.6.5.	Mounting of the arm on the threaded bolts of the interface plate.....	67
6.6.6.	Alignment of the arms with the Interface plate	69
6.6.7.	Assembly of the drop tube on the arms	70
6.6.8.	Installation of the arm lighting (retrofitting only)	72
6.6.9.	Fitting of brake indicators (retrofitting only).....	73
6.7.	Disassembly and assembly of covers.....	74
6.7.1.	Disassembly and assembly of upper decks	74
6.7.2.	Disassembly and assembly of side walls	75
6.8.	Service head assembly.....	76
6.9.	Cable / tube and hose routing.....	77
6.9.1.	Preparation of supply lines for CEILING FIXED ARES.....	78
6.9.2.	Connection of pneumatic brakes.....	79
6.9.3.	Connection of supply and management circuits for electromagnetic or motor brakes.....	81
6.9.4.	Connection of the earthing cables to the support arm.....	83
6.9.5.	Laying of power cables and hoses through the support arm.....	84

6.9.6.	Installation of gas hoses and air exhaust ducts	84
6.9.7.	Connection of the different electrical circuits	86
6.9.8.	Extension arm lighting connection (optional)	87
6.10.	Fitting of trims	88
6.10.1.	Fitting of a single / double trim	88
6.10.2.	Fitting of protective covers. Covers	89
6.10.2.1.	Assembly/disassembly of protective caps on an extension arm	89
6.10.2.2.	Mounting of rear and front covers on a motor or spring arm.....	91
6.10.2.3.	Mounting of rear side covers on a motor or spring arm	92
6.10.2.4.	Rear bottom cover mounting on a motor or spring arm.....	93
6.10.2.5.	Mounting of front side covers on a motor or spring arm	94
6.10.2.6.	Mounting of front top cover on a motor or spring arm	95
6.11.	Mounting of a trolley (optional)	95
6.12.	Adjustments	96
6.12.1.	Adjustment of the mechanical brake on the arms	97
6.12.2.	Adjustment of the mechanical brake on the drop tube (with bearing).....	98
6.12.3.	Adjustment of the mechanical brake on the drop tube (with bearing).....	99
6.12.4.	Adjustment of the rotary stops	99
6.12.5.	Replacement or disassembly of the rotary stops	102
6.12.6.	Assembly of the rotary stops.....	103
6.12.7.	Vertical lift adjustment on the engine arm	104
6.12.7.1.	Opening / closing of the lower rear cover.....	105
6.12.8.	Correcting the vertical alignment of the Service Head on a power arm.....	106
6.12.9.	Adjusting the load capacity on the spring arm	107
6.12.9.1.	Opening / closing of the lower rear cover.....	109
6.12.10.	Adjusting vertical lift on a spring arm	109
6.12.10.1.	Opening/closing of the front top cover	111
6.12.11.	Vertical alignment correction	111
6.13.	Limit switch adjustment for element carriages.....	112
7.	Installation checks.....	113
7.1.	Check the technical characteristics of the equipment to be installed. Weights, torques	114
7.2.	Check the condition of the cables and hoses in the system and the rotation of the arms. 114	
7.1.	Mechanical test	115
7.2.	Check service head enclosure.	115

7.3.	Mechanical crash test	115
7.4.	Gas circuit test	116
7.5.	Electrical circuit tests	116
8.	Regulations	116
8.1.	Team ranking.....	116
8.2.	Reference standards.....	116

ARES

Installation manual

1. Manufacturer

Manufacturer: TEDISEL IBÉRICA S.L.

Address: C/ Sant Lluc, 69-81. 08918 - Badalona (Barcelona) SPAIN

Tel. +34 933 992 058

Fax +34 933 984 547

tedisel@tedisel.com

www.tediselmedical.com



2. Security information

Important notes in these operating instructions are marked with graphic symbols and signal words.

2.1. Injury risk warnings

Signal words such as DANGER, WARNING or CAUTION describe the degree of risk of injury. The different triangular symbols visually emphasise the degree of danger.



WARNING

Refers to a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

Refers to a potential hazard which, if not avoided, may result in minor or slight injury.



DANGER

Refers to an immediate danger which, if not avoided, will result in death or serious injury.



Risk of finger entrapment

2.2. Warnings of risk of damage

The signal word WARNING describes the degree of risk of material damage. The triangular symbol visually emphasises the degree of danger.

Damage to surfaces: warns of damage to surfaces due to unsuitable cleaning agents and disinfectants.



NOTICE

Refers to a potential hazard which, if not avoided, may cause damage to the equipment.

2.3. Additional symbols used in the safety instructions



Fire hazard



Explosion hazard: warns of ignition of explosive gas mixtures.



Dangerous voltage: warns about electric shocks that can cause serious injury or death.



Failure of the roof support system



Risk of collision

2.4. Indication of additional information

NOTA

A NOTE provides additional information and useful tips for safe and efficient use of the device.

2.5. Proper use of oxygen.

2.5.1. Oxygen explosion



Oxygen becomes explosive when it comes into contact with oils, greases and lubricants.

Compressed oxygen presents an explosion hazard:

- Make sure that oxygen and gas outlets are free of oil, greasy materials and lubricants!
- Do not use cleaning agents containing oil, grease or lubricants.

2.5.2. fire hazard



DANGER: Escaping oxygen is combustible:

- Open fire, red-hot objects and open light are not allowed when working.

with oxygen!

- Don't smoke!

2.6. Patient environment

The dimensions in the figure below illustrate the minimum extent of the patient environment in an unrestricted area according to IEC 60601-1.




Fig. 1 Minimum extent of the PATIENT ENVIRONMENT

2.7. Combination with products from other manufacturers.

The suspension system is combined with the service head. To avoid dangerous overloads, which can damage or cause collapse of the service head and the pendant system, the specified maximum load capacity must be observed.



See section 6.7 of the user and cleaning manual supplied with the equipment.

Power supply packages intended to supply power to end devices must ensure electrical isolation and provide two protective measures according to IEC 60601-1.

NOTA

The party putting the device into operation is responsible for the validation of the whole system. If necessary, a conformity assessment procedure shall be performed and a declaration of conformity with Article 22 of the Medical Devices Regulation (EU) 2017/745 shall be provided.



Read the Operating Instructions provided by the external manufacturer to obtain the necessary information for the operation of the end device.

3. Risks

3.1. Gas explosion



Oxygen becomes explosive when it comes into contact with oils, greases and lubricants.

When in contact with oxygen in the air, medical gases may form an explosive or easily flammable gas mixture. The equipment is not suitable for use in environments containing flammable mixtures of anaesthetics with high concentrations of oxygen or nitrous oxide.

If such high concentrations of flammable mixtures of anaesthetics with oxygen or nitrous oxide occur in the environment of the device, there is a risk of ignition under certain conditions.

3.2. Risk of device malfunction



CAUTION: If one device is connected to the equipment and trips the protection mechanism of the corresponding circuit in the health care facility, other devices connected to the equipment will also be de-energised.

3.3. Risk of patient contamination and infection



WARNING: Parts of the pendant system and adaptations are made of plastic. Solvents can dissolve plastic materials. Strong acids, bases and agents with an alcohol content of more than 60 % can cause plastic materials to become brittle. Dislodged particles may fall into open wounds. If liquid cleaning agents are allowed to penetrate the suspension system and fittings, excess cleaning fluid may drip into open wounds.

3.4. Fire risk



Plug-in connections for the supply of medical gases must not come into contact with oil, grease or flammable liquids.

3.5. Danger of electric shock



Signal cables (network, audio, video, etc.) must be electrically isolated from equipment and building connection ends to prevent contact with currents that can cause serious injury or death.

3.6. Risk of collision



In the event of a collision with other devices, walls or ceilings, the pendant system and service head may be damaged and important patient care systems may fail, after a collision, the service head and pendant system should be inspected for damage.

3.7. Risk of system crash due to overload



The dead weights of all attached components and the weight of the attached loads must not exceed the maximum load weight of the base support unit.



If the maximum load capacity has been exceeded, there is a risk that the suspension system or components of the suspension system may become detached from the securing device and fall.



- The maximum load capacity of the suspension system and its components must not be exceeded!

See point 6 of the user and cleaning manual supplied with the equipment.







- Do not attach or mount any additional loads on the extension arms, service head and end devices.

3.8. Risk of system crash due to poor installation



If the fasteners of the individual parts of the system are not correctly positioned or if the tightening torques of the fasteners are not observed, the suspension system may come loose from its fastenings and fall down.

4. Symbols used

	Applicable part B
	Earth (mass)
	Equipotentiality
	Protective earth (ground)
N	Connection point for neutral conductor
	Nurse call button
	Direct lighting
	Indirect lighting
	Operating instructions
MD	Health Product
	Waste electrical equipment



CE symbol



Product code



Unique identification code



Serial number



Manufacturer



Date of manufacture



Reference to the instruction manual



Damage to surfaces



Fire hazard



Danger of explosion



Dangerous tension



Notice

ARES

Installation manual

NOTICE



Risk of finger entrapment



WARNING

Warning



CAUTION

Caution



DANGER

Danger

5. Installation requirements

5.1. Equipment required for installation

- Lifting device or forklift with a permissible payload of at least 250 kg. Alternatively, a lifting winch with a permissible payload of at least 250 kg can be used if space is limited:



CAUTION

Check that the suspension system is sufficiently secured before lifting.



WARNING

During the lifting movement, be sure to avoid collisions with other suspension systems, devices, ceilings or walls and other assemblies.

- Protective gloves
- Digital spirit level
- Torque spanner
- Multimeter
- Standard tool kit
- Spanner 36
- 1 set of telescopic magnet pick-up tools
- Working platform (e.g. pedestal ladder) in accordance with country-specific occupational safety and health standards

5.2. Training

The personnel performing the installation must be properly trained and qualified by the customer. The equipment must only be INSTALLED by authorised personnel. Persons who:

1. have received training and are duly registered (at those levels where legal provisions make such registration necessary).
2. have been instructed in the installation of this device by means of this instruction manual as a basis.
3. are able to assess the tasks they perform on the basis of their own professional experience and training in relevant safety standards and can recognise the potential hazards involved in the work.

6. Installation and connection

6.1. Installation references







Fig. 2 CEILING FIXED ARES

1	Interface plate - pre-assembled (one per downpipe)
2	False Ceiling (own installation)
3	Ceiling trim
	See section 6.10.1 of this manual.
Material included: - 8 countersunk screws M4 x 6mm - 8 screw plugs	
4	Downspout or drop pipe
	See point 6.5 of this manual
Material included: - 4 rod M16 8.8 (length 350mm) - 12 nut DIN934 for M16 - 12 washer DIN125 for M16 - 12 washer Grower DIN127 for M16 - 8 rod M8 8.8 (length 80mm)	
Material included in service head	- 4 spring washer NFE 25511 for M8 (8.2 x 18 x 1.4) - 4 nut DIN934 for M8
5 For attachment to the structural part	- 4 spacer sleeves for downpipe anchorage - 2 plates for downpipe anchoring
	See section 6.8 of this manual








Fig. 3 ARES ROTATION

1	Interface board (Single / Double) - pre-assembled
2	False Ceiling (own installation)
3	Roof trim (depending on version)
	See section 6.10.1 of this manual.
Material included: - 4 / 6 metal screws, 4 / 6 cover screws and 1 sectional strip - 4/6 threaded bolts M10 x 360mm, 4/6 hex nuts M10	
4	Drop tube - friction bearing variant CD.
	See section 6.6.5 of this manual.
Material included: - 1 drop tube CD (length specified in the order) - 1 grounding cable, 4mm ² 1 grounding cable, 4mm ² 1 grounding cable, 4mm ² 1 grounding cable, 4mm - 3 threaded rods M16 x 330mm - 9 hex nuts M16 - 6 spring rings - 6 discs 40 x 50 x 4mm - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 insulating discs	

5	Drop tube - roller bearing variant RR.	
	See section 6.6.5 of this manual.	
Material included:		
<ul style="list-style-type: none"> - 1 RR drop tube (length specified in the order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 3 threaded rods M16 x 330mm - 9 hex nuts M16 - 6 spring rings - 6 discs 40 x 50 x 4mm - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 insulating discs 		
Material included in service head	<ul style="list-style-type: none"> - 4 spring washer NFE 25511 for M8 (8.2 x 18 x 1.4) - 4 nut DIN934 for M8 - 4 spacer sleeves for downpipe anchorage 	
For attachment to the structural part	<ul style="list-style-type: none"> - 2 plates for downpipe anchorage 	
	See section 6.8 of this manual	










Fig. 4 ARES AIR, ARES AIRPLUS, ARES FRICTION

1	Interface plate (Single / Double) - pre-assembled
2	False Ceiling (own installation)
3	Roof trim (depending on version)
	See section 6.10.1 of this manual.
Material included: - 4 / 6 metal screws, 4 / 6 cover screws and 1 sectional strip - 4/6 threaded bolts M10 x 360mm, 4/6 hex nuts M10	

4	Extension arm with pre-assembled roof tube - double arm variant.
	<p>See section 6.6.5 of this manual.</p> <p>Material included:</p> <ul style="list-style-type: none"> - 2 friction-brake extension arms with roof tube - 3 earthing wires, 4mm² 3 grounding wires, 4mm² 3 grounding wires, 4mm² 3 grounding wires, 4mm - 2 set screws M16 - DIN EN ISO 4028 - 4 ball stoppers Ø10mm - DIN 5401, ISO 3290 - 4 End caps for extension arm - 12 hexagon nuts M16 and 6 elastic rings - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm
5	Extension arm with pre-assembled roof tube - single arm variant
	<p>See section 6.6.5 of this manual.</p> <p>Material included:</p> <ul style="list-style-type: none"> - 1 friction brake extension arm with roof tube - 2 earthing cable, 4mm² 2 grounding cable, 4mm² 2 grounding cable, 4mm² 2 grounding cable, 4mm - 1 set screw M16 - DIN EN ISO 4028 - 2 ball stoppers Ø10mm - DIN 5401, ISO 3290 - 2 End caps for extension arm - 12 hex nuts M16 and 6 elastic rings - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm
6	Ceiling tube (for long ceiling tube lengths)
	<p>See section 6.6.2 of this manual.</p> <p>Material included:</p> <ul style="list-style-type: none"> - 1 roof tube (length specified in the order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 1 long pipe spanner (for ceiling pipe lengths of 500 and 700 mm) - 8 socket head cap screws M10 x 25 mm - 8.8 - DIN EN ISO 4762 - 8 lock washers S10

7	Drop tube with friction bearing unit (plain bearing/roller bearing)	
	<p>See section 6.6.7 of this manual.</p> <p>Material included:</p> <ul style="list-style-type: none"> - 1 drop tube (length specified in order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 1 mounting plate 8 x M10 - 8 countersunk socket head cap screws M10 x 25 mm - 8.8 - DIN EN ISO 10642 <p>(Included in the packaging of the service head)</p>	
<p>Material included in service head</p> <p>For attachment to the structural part</p>	<ul style="list-style-type: none"> - 4 spring washer NFE 25511 for M8 (8.2 x 18 x 1.4) - 4 nut DIN934 for M8 - 4 spacer sleeves for downpipe anchorage - 2 plates for downpipe anchorage 	
	<p>See section 6.8 of this manual</p>	








Fig. 5 ARES, ARES INVERTED, ARES XL, ARES XXL

1	Interface board (Single / Double) - pre-assembled
2	False Ceiling (own installation)
3	Roof trim (depending on version)
 See section 6.10.1 of this manual.	
Material included: - 4 / 6 metal screws, 4 / 6 cover screws and 1 sectional strip - 4/6 threaded bolts M10 x 360mm, 4/6 hex nuts M10	

4	Extension arm with pre-assembled roof tube - double arm variant.
	See section 6.6.5 of this manual.
Material included:	<ul style="list-style-type: none"> - 2 pre-mounted brake extension arms (depending on model/s chosen) - 1 power cable - 1 power supply cable for electromagnetic brake - 1 signal cable for electromagnetic brake (in protective tube) - 3 earthing wires, 4mm² 3 grounding wires, 4mm² 3 grounding wires, 4mm² 3 grounding wires, 4mm
	<ul style="list-style-type: none"> - 2 x Screw DIN EN ISO 4028 M16+ 4x ball stop DIN5401, ISO 3290 Ø12,7mm <p>(For ARES and ARES INVERTED)</p>
	<ul style="list-style-type: none"> - 1 x Screw DIN EN ISO 4028 M16+ 2x ball stop DIN5401, ISO 3290 Ø12,7mm - 1 x Screw DIN EN ISO 4028 M20+ 2x ball stop DIN5401, ISO 3290 Ø16mm <p>(For ARES XL)</p>
	<ul style="list-style-type: none"> - 2 x Screw DIN EN ISO 4028 M20+ 4x ball stop DIN5401, ISO 3290 Ø16mm <p>(For ARES XXL)</p>
	<ul style="list-style-type: none"> - 4 End caps for extension arm - 12 hexagon nuts M16 and 6 elastic rings - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm
5	Extension arm with pre-assembled roof tube - single arm variant
	See section 6.6.5 of this manual.
Material included:	<ul style="list-style-type: none"> - 1 extension arm with roof tube - 1 power cable - 1 power supply cable for electromagnetic brake - 1 signal cable for electromagnetic brake (in protective tube) - 2 earthing cable, 4mm² 2 grounding cable, 4mm² 2 grounding cable, 4mm² 2 grounding cable, 4mm
	<ul style="list-style-type: none"> - 2 x Screw DIN EN ISO 4028 M16+ 4x ball stop DIN5401, ISO 3290 Ø12,7mm <p>(For ARES and ARES INVERTED)</p>
	<ul style="list-style-type: none"> - 1 x screw DIN EN ISO 4028 M20+ 2x ball stopper DIN5401, ISO 3290 Ø16mm <p>(For ARES XL)</p>
	<ul style="list-style-type: none"> - 2 End caps for extension arm - 12 hex nuts M16 and 6 elastic rings - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm

6	 Ceiling tube (for long ceiling tube lengths)
	<p>See section 6.6.2 of this manual.</p> <p>Material included:</p> <ul style="list-style-type: none"> - 1 ceiling pipe (length specified in the order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 1 long pipe spanner (for ceiling pipe lengths 500 and 700 mm)
	<ul style="list-style-type: none"> - 8 socket head cap screws M10 x 25 mm - 8.8 - DIN EN ISO 4762 <p>(For ARES and ARES INVERTED)</p>
	<ul style="list-style-type: none"> - 10 hexagon socket head cap screws M10 x 30 mm - 8.8 - DIN EN ISO 4762 <p>(For ARES XL and ARES XXL)</p>
	<ul style="list-style-type: none"> - 8 lock washers S10 <p>(For ARES and ARES INVERTED)</p>
	<ul style="list-style-type: none"> - 10 lock washers S10 <p>(For ARES XL and ARES XXL)</p>
7	Drop tube with friction bearing unit (sliding bearing/roller bearing)
	<p>See section 6.6.7 of this manual.</p> <p>Material included:</p> <ul style="list-style-type: none"> - 1 drop tube (length specified in order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 1 mounting plate 8 x M10
	<ul style="list-style-type: none"> - 8 countersunk socket head cap screws M10 x 25 mm - 8.8 - DIN EN ISO 10642 <p>(Included in the packaging of the service head)</p> <p>(For ARES and ARES INVERTED)</p>
	<ul style="list-style-type: none"> - 8 countersunk socket head cap screws M10 x 30 mm - 8.8 - DIN EN ISO 10642 <p>(Included in the packaging of the service head)</p> <p>(For ARES XL and ARES XXL)</p>
Material included in service head packaging For attachment to the structural part	<ul style="list-style-type: none"> - 4 spring washer NFE 25511 for M8 (8.2 x 18 x 1.4) - 4 nut DIN934 for M8 - 4 spacer sleeves for downpipe anchoring - 2 plates for downpipe anchorage










Fig. 6 ARES MOTOR, ARES MOTOR XL, ARES MOTOR XXL



See section 6.8 of this manual

1	Interface board (Single / Double) - pre-assembled
2	False Ceiling (own installation)
3	Roof trim (depending on version)
	 See section 6.10.1 of this manual. Material included: <ul style="list-style-type: none"> - 4 / 6 metal screws, 4 / 6 cover screws and 1 sectional strip - 4/6 threaded bolts M10 x 360mm, 4/6 hex nuts M10
4	Motorised arm with pre-assembled roof tube - single arm variant
	 See section 6.6.5 of this manual. Material included: <ul style="list-style-type: none"> - 1 motor arm - 1 power cable - 1 power supply cable for electromagnetic brake - 1 signal cable for electromagnetic brake (in protective tube) - 3 earthing wires, 4mm² 3 grounding wires, 4mm² 3 grounding wires, 4mm² 3 grounding wires, 4mm - 1 x screw DIN EN ISO 4028 M16+ 2x ball stopper DIN5401, ISO 3290 Ø12,7mm - 2 voltage selection sockets for power supply 120V / 230V - 2 End caps for extension arm - 4 side panels, front right/left connection for motor arm - 1 cover, rear hinge, for motor arm - 1 cover, front hinge, for motor arm - 2 cover straps, rear hinged, for motor arm - 2 cover straps, front hinged, for motor arm - 12 hexagon nuts M16 and 6 elastic rings - 12 flat washers of 34 mm outer diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm
5	Motorised arm with pre-assembled ceiling tube - double arm variant
	 See section 6.6.5 of this manual. Material included: <ul style="list-style-type: none"> - 1 extension arm with an attached motor arm - 1 power cable - 1 power supply cable for electromagnetic brake - 1 signal cable for electromagnetic brake (in protective tube) - 4 earthing cables, 4mm² (3 for unassembled roof tube)
	<ul style="list-style-type: none"> - 2 x Screw DIN EN ISO 4028 M16+ 4x ball stop DIN5401, ISO 3290 Ø12,7mm <p>(For ARES MOTOR)</p>

		<ul style="list-style-type: none"> - 1 x Screw DIN EN ISO 4028 M16+ 2x ball stop DIN5401, ISO 3290 Ø12,7mm - 1 x screw DIN EN ISO 4028 M20+ 2x ball stopper DIN5401, ISO 3290 Ø16mm <p>(For ARES MOTOR XL)</p>
		<ul style="list-style-type: none"> - 2 voltage selection sockets for power supply 120V / 230V - 4 side panels, front right/left connection for motor arm - 1 cover, rear hinge, for motor arm - 1 cover, front hinge, for motor arm - 2 cover straps, rear hinged, for motor arm - 2 cover straps, front hinge, for motor arm - 12 hex nuts M16 and 6 elastic rings - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm
6	Ceiling tube	
		See section 6.6.2 of this manual.
	Material included:	<ul style="list-style-type: none"> - 1 roof tube (length specified in the order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 1 long pipe spanner (for 500 and 700 mm ceiling pipe lengths)
		<ul style="list-style-type: none"> - 8 socket head cap screws M10 x 25 mm - 8.8 - DIN EN ISO 4762 <p>(For ARES MOTOR)</p>
		<ul style="list-style-type: none"> - 10 hexagon socket head cap screws M10 x 30 mm - 8.8 - DIN EN ISO 4762 <p>(For ARES MOTOR XL)</p>
		<ul style="list-style-type: none"> - 8 lock washers S10 <p>(For ARES MOTOR)</p>
		<ul style="list-style-type: none"> - 10 lock washers S10 <p>(For ARES MOTOR XL)</p>
7	Drop tube	
		See section 6.6.7 of this manual.
	Material included:	<ul style="list-style-type: none"> - 1 drop tube (length specified in order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 1 mounting plate 8 x M10 - 8 countersunk socket head cap screws M10 x 18 mm - 10.9 - DIN EN ISO 10642

(Included in the packaging of the service head)	
Material included in service head	<ul style="list-style-type: none"> - 4 spring washer NFE 25511 for M8 (8.2 x 18 x 1.4) - 4 nut DIN934 for M8 - 4 spacer sleeves for downpipe anchoring
For attachment to the structural part	<ul style="list-style-type: none"> - 2 plates for downpipe anchorage
	See section 6.8 of this manual










Fig. 7 ARES MOTOR AIRPLUS, ARES MOTOR FRICTION

1	Interface board (Single / Double) - pre-assembled
2	False Ceiling (own installation)
3	Roof trim (depending on version)
 See section 6.10.1 of this manual.	
Material included: - 4 / 6 metal screws, 4 / 6 cover screws and 1 sectional strip - 4/6 threaded bolts M10 x 360mm, 4/6 hex nuts M10	

4	Motorised arm with pre-assembled ceiling tube - single arm variant
	See section 6.6.5 of this manual.
Material included:	<ul style="list-style-type: none"> - 1 motor arm - 1 power cable - 2 pneumatic hoses for brake control (only for AIRPLUS) - 3 earthing wires, 4mm² 3 grounding wires, 4mm² 3 grounding wires, 4mm² 3 grounding wires, 4mm
	<ul style="list-style-type: none"> - 1 x Screw DIN EN ISO 4028 M16+ 2x ball stop DIN5401, ISO 3290 Ø12,7mm <p>(For ARES MOTOR AIRPLUS)</p>
	<ul style="list-style-type: none"> - 1 x screw DIN EN ISO 4028 M16+ 2x ball stopper DIN5401, ISO 3290 Ø10mm <p>(For ARES MOTOR FRICTION)</p>
	<ul style="list-style-type: none"> - 2 voltage selection sockets for power supply 120V / 230V - 2 End caps for extension arm - 4 side panels, front right/left connection for motor arm - 1 cover, rear hinge, for motor arm - 1 cover, front hinge, for motor arm - 2 cover straps, rear hinged, for motor arm - 2 cover straps, front hinged, for motor arm - 12 hex nuts M16 and 6 elastic rings - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm
5	Motorised arm with pre-assembled ceiling tube - double arm variant
	See section 6.6.5 of this manual.
Material included:	<ul style="list-style-type: none"> - 1 extension arm with an attached motor arm - 1 power cable - 3 pneumatic tubes for brake control (only for AIRPLUS) - 4 earthing cables, 4mm² (3 for unassembled roof tube)
	<ul style="list-style-type: none"> - 2 x Screw DIN EN ISO 4028 M16+ 4x ball stop DIN5401, ISO 3290 Ø12,7mm <p>(For ARES MOTOR AIRPLUS)</p>
	<ul style="list-style-type: none"> - 2 x Screw DIN EN ISO 4028 M16+ 4x ball stop DIN5401, ISO 3290 Ø10mm

(For ARES MOTOR FRICTION)	
<ul style="list-style-type: none"> - 2 voltage selection sockets for power supply 120V / 230V - 4 side panels, front right/left connection for motor arm - 1 cover, rear hinge, for motor arm - 1 cover, front hinge, for motor arm - 2 cover straps, rear hinged, for motor arm - 2 cover straps, front hinge, for motor arm - 12 hex nuts M16 and 6 elastic rings - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm 	
6	Ceiling tube
	See section 6.6.2 of this manual.
<p>Material included:</p> <ul style="list-style-type: none"> - 1 roof tube (length specified in the order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 1 long pipe spanner (for ceiling pipe lengths of 500 and 700 mm) - 8 socket head cap screws M10 x 25 mm - 8.8 - DIN EN ISO 4762 - 8 lock washers S10 	
7	Drop tube
	See section 6.6.7 of this manual.
<p>Material included:</p> <ul style="list-style-type: none"> - 1 drop tube (length specified in order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 1 mounting plate 8 x M10 - 8 countersunk socket head cap screws M10 x 18 mm - 10.9 - DIN EN ISO 10642 <p>(Included in the packaging of the service head)</p>	
Material included in service head	<ul style="list-style-type: none"> - 4 spring washer NFE 25511 for M8 (8.2 x 18 x 1.4) - 4 nut DIN934 for M8 - 4 spacer sleeves for downpipe anchorage
For attachment to the structural part	<ul style="list-style-type: none"> - 2 plates for downpipe anchorage
	See section 6.8 of this manual










Fig. 8 ARES SPRING AIRPLUS, ARES SPRING FRICTION

1	Interface plate (Single / Double) - pre-assembled
2	False Ceiling (own installation)

3	Roof trim (depending on version)
	<p>See section 6.10.1 of this manual.</p> <p>Material included:</p> <ul style="list-style-type: none"> - 4 / 6 metal screws, 4 / 6 cover screws and 1 sectional strip - 4/6 threaded bolts M10 x 360mm, 4/6 hex nuts M10
4	Spring arm with pre-assembled ceiling tube - single arm variant
	<p>See section 6.6.5 of this manual.</p> <p>Material included:</p> <ul style="list-style-type: none"> - 1 spring-loaded arm - 1 power cable - 3 pneumatic tubes for brake control (AIRPLUS only) - 2 grounding wires, 4mm² 2 grounding wires, 4mm² 2 grounding wires, 4mm² 2 grounding wires, 4mm
	<ul style="list-style-type: none"> - 1 x Screw DIN EN ISO 4028 M16+ 2x ball stop DIN5401, ISO 3290 Ø12,7mm <p>(For ARES SPRING AIRPLUS)</p>
	<ul style="list-style-type: none"> - 1 x screw DIN EN ISO 4028 M16+ 2x ball stopper DIN5401, ISO 3290 Ø10mm <p>(For ARES SPRING FRICTION)</p>
	<ul style="list-style-type: none"> - 2 End caps for extension arm - 4 side panels, front right/left connection for motor arm - 1 cover, rear hinge, for motor arm - 1 cover, front hinge, for motor arm - 2 cover straps, rear hinged, for motor arm - 2 cover straps, front hinged, for motor arm - 12 hexagon nuts M16 and 6 elastic rings - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm
5	Motorised arm with pre-assembled ceiling tube - double arm variant
	<p>See section 6.6.5 of this manual.</p> <p>Material included:</p> <ul style="list-style-type: none"> - 1 extension arm with one spring-loaded arm attached - 1 power cable - 3 pneumatic tubes for brake control (AIRPLUS only) - 3 earthing cables, 4mm² (2 for unassembled roof tube)
	<ul style="list-style-type: none"> - 2 x Screw DIN EN ISO 4028 M16+ 4x ball stop DIN5401, ISO 3290 Ø12,7mm <p>(For ARES SPRING AIRPLUS)</p>

		- 2 x Screw DIN EN ISO 4028 M16+ 4x ball stop DIN5401, ISO 3290 Ø10mm (For ARES SPRING FRICTION)
		- 4 side panels, front right/left connection for motor arm - 1 cover, rear hinge, for motor arm - 1 cover, front hinge, for motor arm - 2 cover straps, rear hinged, for motor arm - 2 cover straps, front hinged, for motor arm - 12 hex nuts M16 and 6 elastic rings - 12 flat washers of 34 mm outer diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm
6	Ceiling tube	
		See section 6.6.2 of this manual.
	Material included:	- 1 ceiling pipe (length specified in the order) - 1 grounding cable, 4mm ² 1 grounding cable, 4mm ² 1 grounding cable, 4mm ² 1 grounding cable, 4mm - 1 long pipe spanner (for ceiling pipe lengths of 500 and 700 mm) - 8 socket head cap screws M10 x 25 mm - 8.8 - DIN EN ISO 4762 - 8 lock washers S10
7	Drop tube	
		See section 6.6.7 of this manual.
	Material included:	- 1 drop tube (length specified in order) - 1 grounding cable, 4mm ² 1 grounding cable, 4mm ² 1 grounding cable, 4mm ² 1 grounding cable, 4mm - 1 mounting plate 8 x M10 - 8 countersunk socket head cap screws M10 x 20 mm - 10.9 - DIN EN ISO 10642 (Included in the packaging of the service head)
	Material included in service head	- 4 spring washer NFE 25511 for M8 (8.2 x 18 x 1.4) - 4 nut DIN934 for M8 - 4 spacer sleeves for downpipe anchorage
	For attachment to the structural part	- 2 plates for downpipe anchorage
		See section 6.8 of this manual











Fig. 9 ARES SPRING, ARES SPRING XL

1	Interface board (Single / Double) - pre-assembled
2	False Ceiling (own installation)
3	Roof trim (depending on version)
	See section 6.10.1 of this manual.
<p>Material included:</p> <ul style="list-style-type: none"> - 4 / 6 metal screws, 4 / 6 cover screws and 1 sectional strip - 4/6 threaded bolts M10 x 360mm, 4/6 hex nuts M10 	

4	Motorised arm with pre-assembled roof tube - single arm variant
 <p>Material included:</p>	<p>See section 6.6.5 of this manual.</p> <ul style="list-style-type: none"> - 1 spring-loaded arm - 1 power cable - 1 power supply cable for the electromagnetic brake - 1 signal cable for electromagnetic brake (in protective tube) - 2 grounding wires, 4mm² 2 grounding wires, 4mm² 2 grounding wires, 4mm² 2 grounding wires, 4mm - 1 x Screw DIN EN ISO 4028 M16+ 2x ball stop DIN5401, ISO 3290 Ø12,7mm - 2 End caps for extension arm - 4 side panels, front right/left connection for spring-loaded arm - 1 cover, rear hinge, for spring-loaded arm - 1 flap, front hinge, for spring-loaded arm - 2 cover straps, rear hinged, for spring-loaded arm - 2 cover straps, front hinge, for spring-loaded arm - 12 hex nuts M16 and 6 elastic rings - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm
5	Spring arm with pre-mounted ceiling tube - double arm variant
 <p>Material included:</p>	<p>See section 6.6.5 of this manual.</p> <ul style="list-style-type: none"> - 1 extension arm with one spring-loaded arm attached - 1 power cable - 1 power supply cable for electromagnetic brake - 1 signal cable for electromagnetic brake (in protective tube) - 3 earthing cables, 4mm² (2 for unassembled roof tube)
	<ul style="list-style-type: none"> - 2 x Screw DIN EN ISO 4028 M16+ 4x ball stop DIN5401, ISO 3290 Ø12,7mm <p>(For ARES SPRING)</p>
	<ul style="list-style-type: none"> - 1 x Screw DIN EN ISO 4028 M16+ 2x ball stop DIN5401, ISO 3290 Ø12,7mm - 1 x screw DIN EN ISO 4028 M20+ 2x ball stopper DIN5401, ISO 3290 Ø16mm <p>(For ARES SPRING XL)</p>

	<ul style="list-style-type: none"> - 4 side panels, right/left front connection for spring-loaded arm - 1 flap, rear hinge, for spring-loaded arm - 1 flap, front hinge, for spring-loaded arm - 2 End caps for extension arm - 2 cover straps, rear hinged, for spring-loaded arm - 2 cover straps, front hinge, for spring-loaded arm - 12 hex nuts M16 and 6 elastic rings - 12 flat washers 34 mm outside diameter and 12 insulating discs - 6 threaded bolts M16 x 330mm
6	Ceiling tube
	See section 6.6.2 of this manual.
Material included:	<ul style="list-style-type: none"> - 1 roof tube (length specified in the order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 1 long pipe spanner (for ceiling pipe lengths of 500 and 700 mm)
	<ul style="list-style-type: none"> - 8 socket head cap screws M10 x 25 mm - 8.8 - DIN EN ISO 4762 <p>(For ARES SPRING)</p>
	<ul style="list-style-type: none"> - 10 hexagon socket head cap screws M10 x 30 mm - 8.8 - DIN EN ISO 4762 <p>(For ARES SPRING XL)</p>
	<ul style="list-style-type: none"> - 8 lock washers S10 <p>(For ARES SPRING)</p>
	<ul style="list-style-type: none"> - 10 lock washers S10 <p>(For ARES SPRING XL)</p>
7	Drop tube with service head
	See section 6.6.7 of this manual.
Material included:	<ul style="list-style-type: none"> - 1 drop tube (length specified in order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 1 mounting plate 8 x M10 - 8 countersunk socket head cap screws M10 x 20 mm - 10.9 - DIN EN ISO 10642 <p>(Included in the packaging of the service head)</p>

8	Drop tube with monitor bracket
	<p>See section 6.6.7 of this manual.</p> <p>Material included:</p> <ul style="list-style-type: none"> - 1 drop tube (length specified in order) - 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm² 1 grounding cable, 4mm - 8 countersunk socket head cap screws M10 x 20 mm - 10.9 - DIN EN ISO 10642 (Included in the packaging of the monitor bracket) - 6 hexagon socket head cap screws M8 x 35 mm - 8.8 - DIN EN ISO 4762 - 6 lock washers S8
<p>Material included in service head</p> <p>For attachment to the structural part</p>	<ul style="list-style-type: none"> - 4 spring washer NFE 25511 for M8 (8.2 x 18 x 1.4) - 4 nut DIN934 for M8 - 4 spacer sleeves for downpipe anchorage - 2 plates for downpipe anchorage
	<p>See section 6.8 of this manual</p>

6.2. Installation references. Accessories. Lighting, indicators.

When the system is delivered ex works, the following optional accessories are already fitted:







Fig. 10 Arms with friction or pneumatic brakes

9	<p>Indirect lighting of the extension arm (extension arm length 800 and 1000 mm) ARES SPRING (extension arm length 1000, 1200, 1400 and 1600 mm)</p>
	<p>an update:</p> <p>See section 6.6.8 of this manual.</p> <ul style="list-style-type: none"> - 1 extension arm lighting (600 mm long, input voltage 12 V DC) - 3 sealing plugs at the top of the extension arm - 1 basic stand with LED and connection cable - 1 electrical signal cable, with connectors at both ends - 1 pouch - 2 countersunk screws M4 x 16 mm - DIN EN ISO 10642 <p>- (optional) 1 set of telescopic magnet pick-up tools</p>

ARES

Installation manual








Fig. 11 Electromagnetically braked arms

9	Indirect lighting of the extension arm
	<p>ARES (extension arm length 800, 1000 and 1200 mm)</p> <p>ARES INVERTED (extension arm length 800, 1000 and 1200 mm)</p> <p>ARES XL and XXL (extension arm lengths 1000, 1200, 1400 and 1600 mm)</p> <p>ARES MOTOR (extension arm length 800, 1000 and 1200 mm)</p> <p>ARES MOTOR XL (extension arm length 1000, 1200, 1400 and 1600 mm)</p> <p>ARES SPRING (extension arm length 1000, 1200, 1400 and 1600 mm)</p>
	<p>For an update:</p> <p> See section 6.6.8 of this manual.</p> <ul style="list-style-type: none"> - 1 extension arm lighting (600 mm long, input voltage 12 V DC) - 3 sealing plugs at the top of the extension arm - 1 basic stand with LED and connection cable - 1 electrical signal cable, with connectors at both ends - 1 pouch - 2 countersunk screws M4 x 16 mm - DIN EN ISO 10642
10	Brake indicators (for single and double arm extensions):
	<p>For an update:</p> <p> See section 6.6.9 of this manual.</p> <ul style="list-style-type: none"> - 2 / 4 plastic covers (pre-assembled) - 2 / 4 lighting boards (12 V DC supply voltage) (2 lighting boards each connected in series to the 24 V DC supply) - 2/4 power cables <p>- (optional) 1 set of telescopic magnet pick-up tools</p>

6.3. Additional instructions

The following parts should be available:




Fig. 12 Outline of instructions

6.4. Loading data

The data required for the calculation of the ceiling load are given in the following tables. When mounting the suspension system, the vertical weight force of the intermediate ceiling assembly (the values correspond to the maximum load) must be added to the corresponding values of the suspension system to determine the ceiling load.



The safety factors prescribed in the individual regions.

This must be taken into account when calculating the maximum load data!

The table shows the values for the maximum permissible load capacity of the suspension system, single version. The load data of a tandem version can be calculated from the sum of the individual ones. Picture on the right in figure 13.




Fig. 13 Load calculation scheme

6.4.1. CEILING FIXED ARES, ARES ROTATION

Fixed ceiling version without rotation	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Length 120mm - 1500mm	6349	1300	-	600
Sliding bearing version CD	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Length 120mm - 1800mm	4074	1300	747	385
Roller bearing version RR	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Length 220mm - 1800mm	4074	1300	747	385

6.4.2. ARES AIR

Single arm versions	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm]	Load G [kg]
Extension arm 600mm	6017	1300	3457	580
Extension arm 800mm	4477	1300	3405	420
Extension arm 1000mm	3525	1300	3300	320
Double arm versions	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm]	Load G [kg]
Extension arm 600mm / 600mm	3116	1300	3286	260

Extension arm 600mm / 800mm	2753	1300	3288	220
Extension arm 800mm / 600mm	2753	1300	3322	220
Extension arm 800mm / 800mm	2391	1300	3173	180
Extension arm 600mm / 1000mm	2391	1300	3140	180
Extension arm 800mm / 1000mm	2126	1300	3050	150
Extension arm 1000mm / 600mm	2391	1300	3206	180
Extension arm 1000mm / 800mm	2126	1300	3083	150

6.4.3. ARES AIRPLUS AND ARES FRICTION

Single arm versions	Weight (F _G) [N] [N]	Weight (F _A) [N] Anchor kit	Max. bending moment M _B [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm	6605	1300	3810	640
Extension arm 800mm	4967	1300	3758	470
Extension arm 1000mm	4016	1300	3790	370
Double arm versions	Weight (F _G) [N] [N]	Weight (F _A) [N] Anchor kit	Max. bending moment M _B [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm / 600mm	3508	1300	3757	300
Extension arm 600mm / 800mm	3146	1300	3838	260
Extension arm 800mm / 600mm	3146	1300	3871	260
Extension arm 800mm / 800mm	2783	1300	3801	220
Extension arm 600mm / 1000mm	2783	1300	3768	220
Extension arm 800mm / 1000mm	2518	1300	3756	190
Extension arm 1000mm / 600mm	2783	1300	3834	220
Extension arm 1000mm / 800mm	2518	1300	3789	190
Extension arm 1000mm / 1000mm	2352	1300	3829	170

6.4.4. ARES AND ARES INVERTED

Single arm versions	Weight (F _G) [N] [N]	Weight (F _A) [N] Anchor kit	Max. bending moment M _B [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm	6834	1300	3815	640
Extension arm 800mm	5196	1300	3764	470
Extension arm 1000mm	4245	1300	3739	370

Extension arm 1200mm	3587	1300	3680	300
Double arm versions	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm]	Load G [kg]
Extension arm 600mm / 600mm	3737	1300	3761	300
Extension arm 600mm / 800mm	3374	1300	3842	260
Extension arm 600mm / 1000mm	3011	1300	3773	220
Extension arm 600mm / 1200mm	2746	1300	3728	190
Extension arm 800mm / 600mm	3374	1300	3875	260
Extension arm 800mm / 800mm	3011	1300	3806	220
Extension arm 800mm / 1000mm	2747	1300	3762	190
Extension arm 800mm / 1200mm	2580	1300	3802	170
Extension arm 1000mm / 600mm	3012	1300	3839	220
Extension arm 1000mm / 800mm	2747	1300	3795	190
Extension arm 1000mm / 1000mm	2580	1300	3835	170
Extension arm 1000mm / 1200mm	2413	1300	3803	150
Extension arm 1200mm / 600mm	2747	1300	3828	190
Extension arm 1200mm / 800mm	2580	1300	3868	170
Extension arm 1200mm / 1000mm	2413	1300	3836	150
Extension arm 1200mm / 1200mm	2247	1300	3731	130

6.4.5. ARES XL

Single arm versions	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm	10315	1300	5953	1000
Extension arm 800mm	8598	1300	6544	820
Extension arm 1000mm	6980	1300	6537	650
Extension arm 1200mm	5950	1300	6697	540
Extension arm 1400mm	5410	1300	6886	480
Extension arm 1600mm	4674	1300	6653	400
Double arm versions	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm / 600mm	5943	1300	6488	530
Extension arm 600mm / 800mm	5384	1300	6746	470

Extension arm 800mm / 600mm	5404	1300	6795	470
Extension arm 800mm / 800mm	4648	1300	6509	390
Extension arm 600mm / 1000mm	4433	1300	6146	370
Extension arm 800mm / 1000mm	4089	1300	6268	330
Extension arm 1000mm / 600mm	4668	1300	6562	390
Extension arm 600mm / 1200mm	3776	1300	5689	300
Extension arm 1000mm / 800mm	4109	1300	6321	330
Extension arm 1200mm / 600mm	4128	1300	6378	330
Extension arm 800mm / 1200mm	3825	1300	6386	300
Extension arm 1000mm / 1000mm	3844	1300	6439	300
Extension arm 1000mm / 1200mm	3579	1300	6446	270
Extension arm 1200mm / 800mm	3864	1300	6496	300
Extension arm 1200mm / 1000mm	3599	1300	6502	270
Extension arm 1200mm / 1200mm	3334	1300	6397	240
Extension Arm 1400mm / 600mm	3883	1300	6556	300
Extension arm 1400mm / 800mm	3618	1300	6563	270
Extension Arm 1400mm / 1000mm	3354	1300	6458	240
Extension Arm 1400mm / 1200mm	2991	1300	5986	200
Extension arm 1600mm / 600mm	3638	1300	6627	270
Extension arm 1600mm / 800mm	3373	1300	6522	240
Extension arm 1600mm / 1000mm	3010	1300	6050	200

6.4.6. ARES XXL

Double arm versions	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm / 600mm	6196	1300	6719	540
Extension arm 600mm / 800mm	5656	1300	7023	480
Extension arm 800mm / 600mm	5656	1300	7074	480
Extension arm 800mm / 800mm	4921	1300	6839	400
Extension arm 600mm / 1000mm	4921	1300	6788	400
Extension arm 800mm / 1000mm	4381	1300	6653	340
Extension arm 1000mm / 600mm	4921	1300	6890	400
Extension arm 600mm / 1200mm	4381	1300	6602	340
Extension arm 1000mm / 800mm	4381	1300	6704	340
Extension arm 1200mm / 600mm	4381	1300	6755	340

Extension arm 800mm / 1200mm	4136	1300	6830	310
Extension arm 800mm / 1400mm	3891	1300	6899	280
Extension arm 1000mm / 1000mm	4136	1300	6881	310
Extension arm 1000mm / 1200mm	3891	1300	6950	280
Extension arm 1000mm / 1400mm	3645	1300	6911	250
Extension arm 1000mm / 1600mm	3302	1300	6510	210
Extension arm 1200mm / 800mm	4136	1300	6932	310
Extension arm 1200mm / 1000mm	3891	1300	7001	280
Extension arm 1200mm / 1200mm	3645	1300	6963	250
Extension Arm 1200mm / 1400mm	3302	1300	6561	210
Extension Arm 1400mm / 600mm	4136	1300	6983	310
Extension arm 1400mm / 800mm	3891	1300	7053	280
Extension Arm 1400mm / 1000mm	3645	1300	7014	250
Extension Arm 1400mm / 1200mm	3302	1300	6612	210
Extension arm 1600mm / 600mm	3891	1300	7104	280
Extension arm 1600mm / 800mm	3645	1300	7065	250
Extension arm 1600mm / 1000mm	3302	1300	6663	210

6.4.7. ARES MOTOR, ARES MOTOR XL, ARES MOTOR XXL

Single arm versions	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
COLUMN MOTOR	2195	1300	1550	150
COLUMN MOTOR XL	2784	1300	2150	210
COLUMN MOTOR XXL	3176	1300	2550	250
Double arm versions (Extension Arm + COLUMN MOTOR)	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm	2387	1300	2800	150
Extension arm 800mm	2417	1300	3250	150
Extension arm 1000mm	2446	1300	3700	150
Extension arm 1200mm	2378	1300	3900	140
Double arm versions (Extension arm + COLUMN MOTOR XL)	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]

Extension arm 600mm	2975	1300	3750	210
Extension arm 800mm	2711	1300	3750	180
Extension arm 1000mm	2544	1300	3850	160
Extension arm 1200mm	2376	1300	3900	140
Double arm versions (Extension arm + COLUMN MOTOR XXL)	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm	3609	1300	4400	250
Extension arm 800mm	3658	1300	5050	250
Extension arm 1000mm	3707	1300	5700	250
Extension arm 1200mm	3756	1300	6400	250
Extension arm 1400mm	3707	1300	6800	240
Extension arm 1600mm	3364	1300	6450	200

6.4.8. ARES MOTOR AIRPLUS, ARES MOTOR FRICTION

Single arm versions	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
COLUMN MOTOR	2195	1300	1550	150
COLUMN MOTOR XL	2784	1300	2150	210
COLUMN MOTOR XXL	3176	1300	2550	250
Double arm versions (Extension Arm + COLUMN MOTOR)	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm	2387	1300	2800	150
Extension arm 800mm	2417	1300	3250	150
Extension arm 1000mm	2446	1300	3700	150
Double arm versions (Extension arm + COLUMN MOTOR XL)	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm	2975	1300	3750	210
Extension arm 800mm	2711	1300	3750	180
Extension arm 1000mm	2544	1300	3850	160

6.4.9. ARES SPRING AIRPLUS, ARES SPRING FRICTION

Single arm versions	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
COLUMN SPRING	2578	1300	1900	180
Double arm versions (Extension arm + COLUMN SPRING)	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm	2770	1300	3450	180
Extension arm 800mm	2701	1300	3800	170
Extension arm 1000mm	2535	1300	3900	150
Extension arm 1200mm (Only for CEMOR monitor bracket)	2368	1300	3950	130

6.4.10. ARES SPRING E-BRAKE

Single arm versions	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
COLUMN SPRING	2578	1300	1900	180
Double arm versions (Extension arm + COLUMN SPRING)	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Extension arm 600mm	2770	1300	3450	180
Extension arm 800mm	2701	1300	3800	170
Extension arm 1000mm	2535	1300	3900	150
Extension arm 1200mm	2368	1300	3950	130
Double arm versions (XL Extension Arm + COLUMN SPRING)	Weight (FG) [N] [N]	Weight (FA) [N] Anchor kit	Max. bending moment MB [Nm] [Nm] [Nm]	Load G [kg]
Extension arm XL 600mm	2948	1300	3450	180
Extension arm XL 800mm	2997	1300	4000	180
Extension arm XL 1000mm	3046	1300	4550	180
Extension arm XL 1200mm	3095	1300	5100	180
Extension arm XL 1400mm	3144	1300	5650	180

Extension arm XL 1600mm	3193	1300	6250	180
-------------------------	------	------	------	-----

6.4.11. Service head and accessories

In this section the weights for the different service heads attachable to the pendant system are given without taking into account the electrical, communication and gas hoses. These weights must be taken into account when checking the payload given in this chapter for the different configurations of the pendant system in addition to any accessories that may be attached to the service heads.

Service head (700mm)	28kg
Service head (900mm)	35kg
Service head (1000mm)	38kg
1m 38mm diameter tube set for attachment of accessories.....	3kg
Drawer in horizontal service head	14kg
Flange assembly for 38mm diameter pipe.....	0,35kg
Stainless steel double technical rail set on 38mm diameter tube (L=500mm)	1,6kg
Double technical stainless steel rail set on 38mm diameter tube (L=700mm)	2kg
Technical aluminium double rail set on 38mm diameter tube (L=500mm)	1,4kg
Technical aluminium double rail set on 38mm diameter tube (L=700mm)	1,7kg

6.5. Mounting of threaded bolts on the interface plate

6.5.1. Installation without false ceiling




Fig. 14 Installation of interface plate without false ceiling

- Cut the threaded bolts to length.

If an interface plate (1) is mounted on the intended slab or structure, the threaded bolts M16 x 330 mm (3) (6 in the single version, 12 in the double version) must be cut to size.

- The roof trim (3) will later be mounted flush with the roof and covers the roof pipe flange.
- For the ceiling trim (3), which has a height of 260 mm, the 6/12 M16 x 330 mm threaded bolts (3) must be cut to 240 mm (max. 245 only for COLUMN ROTATION). See Fig. 14.
- Lightly deburr the M16 x 330 mm threaded bolts (1) to ensure maximum thread engagement in the interface plate (1).
- Thread 1 M16 hex nut (2) each onto the M16 threaded bolts (3) and then fit 1 spring washer (1) each.



If the M16 threaded bolts (3) (3) are not completely screwed in, they can come out of the interface plate (1) and cause the system to fall down.

- Check that the shortened M16 threaded bolts (3) are securely fastened at the correct distance from each other and fully screwed into the interface plate 1.



The M16 hex nuts (2) must be tightened to 195 Nm.




Fig. 15 Fitting of the upper insulation to the threaded bolts without a false ceiling

- For each M16 threaded bolt (1) screw an M16 hexagon nut (2) onto the M16 threaded bolts (1).

The M16 hexagon nuts (2) (6 for single version, 12 for double version) must be mounted on the M16 threaded bolts (1) at exactly the right distance from each other.

- Adjust the distance between the M16 hex nuts (2) and the interface plate from 1 to 150mm.
- Using a digital spirit level, align the M16 hex nuts (2) horizontally.
- Fit 1 flat washer with an outer diameter of 34 mm (3).

- Place 1 plastic insulating disc (4) (as shown in figure 15) in such a way that the flat washer with an outer diameter of 34 mm (3) sits on the plastic insulating disc (4).
- Secure the plastic insulating disc (4) to the M16 threaded bolts (1) with adhesive or elastic tape.

6.5.1.1. Installation without false ceiling for CEILING FIXED ARES




Fig. 16 Installation of interface plate without false ceiling for CEILING FIXED ARES

- Cut the threaded bolts (3) to length.

If an interface plate (1) is mounted on the intended slab or structure, the threaded bolts M16 x 350 mm (3) must be cut to size.

- The ceiling trim (3) is later mounted flush with the ceiling and covers the counter plate (4).
- For the ceiling trim (3), which has a height of 300 mm, the 6/12 M16 x 350 mm threaded bolts (3) must be cut to 280 mm. See Fig. 16.
- Lightly deburr the M16 x 350 mm threaded bolts (3) to ensure maximum thread engagement in the interface plate (1).
- Thread 1 M16 hex nut (2) each onto the M16 threaded bolts (3) and then fit 1 spring washer (1) each.



If the M16 threaded bolts (3) (3) are not completely screwed in, they may come out of the interface plate (1) and cause the system to fall down.

- Check that the shortened M16 threaded bolts (3) are securely fastened at the correct distance from each other and fully screwed into the interface plate 1.



The M16 hex nuts ② must be tightened to 195 Nm.

6.5.2. Installation with false ceiling




Fig. 17 Installation of interface plate with false ceiling

- Cut the threaded bolts to length.

If an interface plate (1) is mounted on the intended slab or structure, the threaded bolts M16 x 330 mm ③ (6 in the single version, 12 in the double version) must be cut to size.

- The roof trim (3) will later be mounted flush with the roof and covers the roof pipe flange.
- The required length of the threaded bolts M16 x 330 mm ① depends on the distance H: from the roof to the lower edge of the intermediate ceiling 2.
- Please note the minimum and maximum length of the threaded bolts M16 x 330 mm ①.
- For the ceiling trim (3), which has a height of 150 mm, the 6/12 M16 x 330 mm threaded bolts ③ must be cut as shown in Fig. 17.
- To determine the LG length of the threaded bolts ①, $LG=H +135\text{mm}$ (min. 205mm / max. 245mm)
- Lightly deburr the M16 x 330 mm threaded bolts ① to ensure maximum thread engagement in the interface plate (1).
- Thread 1 M16 hex nut ② each onto the M16 threaded bolts ③ and then fit 1 spring washer ① each.



If the M16 threaded bolts ③ ③ are not completely screwed in, they may come out of the interface plate (1) and cause the system to fall down.

- Check that the shortened M16 threaded bolts ③ are securely fastened at the correct distance from each other and fully screwed into the interface plate 1.



The M16 hex nuts ② must be tightened to 195 Nm.




Fig. 18 Fitting of the upper insulation to the threaded bolts without a false ceiling

- For each M16 threaded bolt ① screw on an M16 hexagon nut ②.

The M16 hexagon nuts ② (6 for single version, 12 for double version) must be mounted on the M16 threaded bolts ① at exactly the right distance from each other.

- Set the distance between the M16 hex nuts ② and the interface plate from 1 to $L = LG - 95$ mm (min. 110 mm / 150 mm).
- Screw the hexagon nuts M16 ② onto the M16 threaded bolts ① at the calculated distance L.
- Using a digital spirit level, align the M16 hex nuts ② horizontally.
- Fit 1 flat washer with an outer diameter of 34 mm ③.
- Place 1 plastic insulating disc ④ (as shown in figure 18) in such a way that the flat washer with an outer diameter of 34 mm ③ sits on the plastic insulating disc ④.
- Secure the plastic insulating disc ④ to the M16 threaded bolts ① with adhesive or elastic tape.

6.5.2.1. Installation with false ceiling for CEILING FIXED ARES




Fig. 19 Installation of the interface plate in a room with false ceiling

There are two different configurations if a downpipe is installed in a room with a false ceiling. One possibility is that the distance between the floor and the false ceiling completely covers the length LG of the threaded bolts (3), in this case a flat ceiling trim with a height of 10mm is supplied as shown in the upper right part of figure 6. The other possibility is that the distance between the floor and the false ceiling is not sufficient for a correct installation and energy supply passage, in this case a trim of 150mm in height can be ordered (optional) as shown in the lower right part of figure 19.

- Cut the threaded bolts M16 x 350 mm (3) to length if necessary.
- The ceiling trim (3) will be fitted flush with the false ceiling at a later date. It covers the counter plate (4).
- If the threaded bolts M16 x 350 mm (3) have been cut, remove the burrs to ensure maximum thread engagement in the interface plate (1).



Fit 1 spring washer (1) and screw 1 M16 hex nut (2) each onto the M16 threaded bolts (3).

If the M16 threaded bolts (3) (3) are not completely screwed in, they may come out of the interface plate (1) and cause the system to fall down.

- Check that the shortened M16 threaded bolts (3) are securely fastened at the correct distance from each other and fully screwed into the interface plate 1.



The M16 hex nuts (2) must be tightened to 195 Nm.

6.5.3. Mounting of interface plate on the false ceiling bracket




Fig. 20 Mounting of interface plate with false ceiling

The threaded bolts M16 x 330 mm (3) (6 for single version, 12 for double version) must protrude from face plate (1).



To ensure sufficient strength, the M16 threaded bolts (1) must not exceed a maximum length of 330 mm.

- Screw 1 M16 hex nut (2) each onto the 6/12 M16 x 330 mm threaded bolts (3) and then fit 1 spring ring (1) each.
- All threaded bolts M16 x 330 mm (3) must be completely screwed into the interface plate 1.

The threaded bolts M16 x 330 mm (3) must protrude from the interface plate (1) 220 mm in both the single and double version. In COLUMN ROTATION minimum 130mm and maximum 170mm.

- Check that the shortened M16 threaded bolts (3) are securely fastened at the correct distance from each other and fully screwed into the interface plate 1.



The M16 hex nuts (2) must be tightened to 195 Nm.




Fig. 21 Installation of the upper insulation to the threaded bolts with false ceilings

- For each M16 threaded bolt ① screw an M16 hexagon nut ② onto the M16 threaded bolts ①.

The M16 hexagon nuts ② (6 for single version, 12 for double version) must be mounted on the M16 threaded bolts ① at exactly the right distance from each other.

- Adjust the distance between the M16 hex nuts ② and the interface plate from 1 to 150mm.
- Screw the hexagon nuts M16 ② onto the M16 threaded bolts ① at the calculated distance L.
- Using a digital spirit level, align the M16 hex nuts ② horizontally.
- Fit 1 flat washer with an outer diameter of 34 mm ③.
- Place 1 plastic insulating disc ④ (as shown in figure 13) in such a way that the flat washer with an outer diameter of 34 mm ③ sits on the plastic insulating disc ④.

6.6. Pre-assembly: Ceiling tube (included), drop arm and drop tube

6.6.1. Description of components

This section describes the components involved in this manual. For the long roof tube variants or for ARES INVERTED, the roof tube (6) is included in the scope of delivery as an individual part.

- The roof tube (6) is mounted on the arms (4), (5) (double and single arm variant).
- The following simplified figures illustrate the different configurations without pre-assembled cables.
- The installation is described in the following chapters and is identical for the different versions.
- Please note the different length and number of fixing screws for the different versions.




Fig. 22 ARES AIR, ARES AIRPLUS, ARES FRICTION




Fig. 23 ARES, COLUMN XL, ARES XXL




Fig. 24 ARES MOTOR, ARES MOTOR XL




Fig. 25 ARES MOTOR AIRPLUS, ARES MOTOR FRICTION




Fig. 26 ARES SPRING AIRPLUS, ARES SPRING FRICTION

ARES

Installation manual




Fig. 27 ARES SPRING, ARES SPRING XL

- The drop tubes (7) are mounted on the arm (4) for single arm systems and on the arm (5) for double arm systems. This tube will have different heights to adjust the overall height of the service head. A special drop tube variant (8) is available for spring-loaded arms with CEMOR monitor bracket.

ARES

Installation manual




Fig. 28 Drop tubes

6.6.2. Ceiling tube mounting




Fig. 29 Mounting the roof tube

- Place the roof tube (6) over the extension arms (4), (5) and position it so that the chamfered surface ③ is almost at right angles to the extension arms (4), (5), as shown in the figure.
- Assign the fastening screws to the individual ceiling tube type (6) according to the chosen configuration:

Anchorage for single arm systems: 8 socket head cap screws M10 x 25 mm ① - 8,8 - DIN EN ISO 4762 and 8 lock washers S10 ②.

Anchoring on extension arm: 8 socket head cap screws M10 x 25 mm ① - 8,8 - DIN EN ISO 4762 and 8 lock washers S10 ②.

Anchoring on extension arm XL (higher load capacity): 10 hexagon socket head cap screws M10 x 30 mm ① - 8,8 - DIN EN ISO 4762 and 10 lock washers S10 ②.

- Mount the selected screws ① with the corresponding lock washers ②.

- In the position of the pre-assembled cable ④, leave the threaded hole ⑤ free.
- Screw the roof tube (6) to the extension arms (4), (5) with 7 / 9 screws of the selected model and the corresponding lock washers S10 ②).
- Use an extension tool to tighten the 7 / 9 M10 socket head cap screws ① - DIN EN ISO 4762.

The 7 M10 socket head cap screws ① - DIN EN ISO 4762 must be fitted with 7 lock washers ② and tightened to 40 Nm.



- Mount the strain relief mechanism on the roof tube (6).

See section 6.6.3 of this manual.

6.6.2.1. Mounting of ceiling tube for CEILING FIXED ARES

In the case of ceiling fixed equipment without rotation (CEILING FIXED ARES) the ceiling pipe and the drop pipe are the same, so this section closes the installation for this variant.




Fig. 30 Installation of the downpipe on the interface plate

- For each M16 threaded bolt ① screw on an M16 hexagon nut ②).

The M16 hex nuts ② must be mounted on the M16 threaded bolts ① at exactly the right distance from each other.

- Adjust the distance between the M16 hex nuts ② and the interface plate from 1 to 150mm.
- Using a digital spirit level, align the M16 hex nuts ② horizontally.
- Fit 1 flat washer with an outer diameter of 34 mm ③.
- Secure the flat washer ③ with adhesive or elastic tape on the threaded bolts ①.
- Fit the downpipe by passing the threaded bolts through the 16.5 mm holes in the counter plate ④.
- Fit a flat washer with an outer diameter of 34 mm ③.
- For each M16 threaded bolt ① screw on an M16 hexagon nut ② to secure the downpipe.

6.6.3. Mounting tension release mechanism on the ceiling tube




Fig. 31 Mounting the strain relief mechanism

Figure 31 shows the roof tube 6 with 8 hexagon socket head cap screws M10 x 25 mm ① - 8.8 - DIN EN ISO 4762 as an example.

- Insert an M10 x 25 mm socket head cap screw ① or an M10 x 30 mm socket head cap screw ① and an S10 lock washer ② into the cable gland bracket ④.

- Position the grommet bracket ④ on the roof tube 6 in such a way that the cut-out ③ of the grommet bracket ④ points towards the wall of the roof tube.
- Place the pre-assembled cable ⑦ in the cut-out ③ of the cable gland holder ④.
- Screw the cable gland bracket ④ to the motor arm (4), extension arm with motor arm (5) or XL extension arm with motor arm (5) using the socket head cap screw ① and lock washer ②.
- Make sure that the cable is not ⑦ tight.
- Establish the plug connection ⑤/⑥ with the control cable included in the packaging ⑨ and then push the strain relief mechanism ⑧ into the strain relief bracket ④.
- Check that the strain relief mechanism ⑧ is correctly fitted:
- The control cable ⑨ must be securely unloaded into the strain relief mechanism ④.
- Route the control cable ⑨ through the roof tube (6) and the motor arm (4) or the extension arm with the motor arm (5) or the XL extension arm with the motor arm (5) to the distributor plate.



The M10 socket head cap screw ① - DIN EN ISO 4762 must be fitted with the lock washer ② and tightened to 40 Nm.

6.6.4. Roof tube earthing cable assembly




Fig. 32 Mounting of the earthing cable on the drop tube for ARES ROTATION arms and ARES ROTATION

The system is delivered with pre-assembled earthing cable!

- Mount 1 S4 lock washer ②/④ above and below the round terminal ③ of the 4 mm² earthing cable (approx. 1 m long) included in the packaging.
- Using 1 socket head cap screw M4 x 12 mm - DIN 912 ①, screw the cable lug ③ and the lock washers S4 ②/④ to the earthing point ⑤.
- Tighten the M4 x 12 mm socket head cap screw ①.

6.6.5. Mounting of the arm on the threaded bolts of the interface plate

In this section we already have the system arm(s) attached to the ceiling tube as shown in figure 33. The single arm ARES AIR has been fixed to an extension ceiling tube so that the two suspended systems do not collide when rotating.




Fig. 33 Double-arm ARES AIR and single-arm ARES AIR

Figure 34 shows a simplified representation of the roof tube flange ⑥ for mounting on the threaded bolts. Other components such as extension arm, cables, etc. are not shown.




Fig. 34 Assembly of the roof tube flange on the threaded bolts



Make sure that no one is under the hanging system.

Risk of falling parts.

- Securely fasten the roof tube flange (6) or, using a suitable lifting device, place it under the M16 threaded bolts (1) of the interface plate (1).

NOTA

When mounting double systems, it should be noted that the flanges of the roof pipes (6) have a chamfered surface to ensure that they can be mounted at the same height, mount them so that the chamfered surfaces are aligned with each other, as shown in figure 33 .

- Insert the roof tube flange (6) into the 6 M16 threaded bolts (1) of the interface plate (1).
- Remove the previously applied adhesive or elastic tape from the threaded bolts (1).
- For each M16 threaded bolt (1), fit 1 plastic insulating disc (2) (as shown in Figure 34) so that the flat washer with an outer diameter of 34 mm (3) (see arrow in the detailed illustration in Figure 31) is seated on the plastic insulating disc (2).
- For each M16 threaded bolt (1), fit 1 flat washer with an external diameter of 34 mm (3), 1 spring disc (4) and 1 M16 hexagon nut (5).

6.6.6. Alignment of the arms with the Interface plate




Fig. 35 Aligning the arms with the Interface plate

- Choose 1 of the 6 M16 hex nuts (2) as a reference point.
- Screw the 6 M16 hex nuts (2) (2) under the flange (3) crosswise onto the flange (3) and tighten to 100 Nm.



Tighten the M16 hex nuts (2) on the flange to a torque of 100 Nm.





Fig. 36 Checking the horizontal alignment of the outriggers

NOTA

For double arm variants, remove the transport lock (belt) and remove the pre-assembled swivel stop if necessary. Then rotate the lower arm relative to the upper arm.

- Check the horizontal alignment of the extension arms. Place the digital spirit level at right angles to the direction of the arm (near the flange ③). Rotate the arm 90 degrees in various directions and check the horizontal alignment. See Fig. 36.

NOTA

In case of deviations of more than ± 0.2 degrees, the arms must be realigned. To do this, repeat the installation steps described above.

- Check that all M16 hex nuts ② ② are correctly positioned and tightened once the arms are properly aligned.

6.6.7. Assembly of the drop tube on the arms

Optionally, the service head can be ordered already assembled to the drop tube. In this case, the various electrical and gas hoses are routed through the drop tube. Before mounting the drop tube on the suspension system, all electrical and gas hoses must be routed through the suspension system.

See section 6.9 of this manual.



For non-powered arms. The figure shows an enlarged section view of the extension arm without its upper part.




Fig. 37 Assembly of drop tube on NON-motorised arms

- Insert the fixing plate 8 x M10 ③ from the front side ① into the extension arm (4), (5) and fit it.
- Place the drop tube under the extension arm (4) / (5) so that the end stop ④ on the drop tube points away from the side of the extension arm and the fixing holes are aligned.
- In order to be able to rotate the service head counterclockwise, the drop tube must be mounted with the end stop ④ on the right side, as shown in figure 37. It will be mounted on the left side if the service head is to be able to rotate clockwise.
- Fix the drop tube through the 8 x M10 fixing plate ③ and screw it to the extension arm (4), (5) with 8 countersunk Allen screws ②.

ARES and ARES INVERTED, ARES XL (double arm variant): 8 countersunk hexagon socket screws M10 x 25 mm ② - 10.9 - DIN EN ISO 10642

ARES XL (single arm variant) and ARES XXL: 8 countersunk hexagon socket screws M10 x 30 mm ② - 10.9 - DIN EN ISO 10642



The M10 countersunk screws ② - DIN EN ISO 10642 must be tightened to 40 Nm.

For motorised or spring-loaded arms. Figure 38 shows an enlarged section view of the motorised arm (on the right in Fig. 38) and the spring arm (on the left in Fig. 38) without its upper part.




Fig. 38 Assembly of drop tube on motorised and spring-loaded arms

- Position the drop tube under the arm (4) / (5) so that the end stop (4) on the drop tube points away from the side of the extension arm and the fixing holes are aligned.
- In order to be able to rotate the service head counterclockwise, the drop tube must be mounted with the end stop (2) on the right-hand side, as shown in figure 38. It shall be mounted on the left side if the service head is to be able to rotate clockwise.
- Fix the drop tube through the 8 x M10 fixing plate (3) and screw it to the extension arm (4) / (5) with 8 countersunk Allen screws (1).

ARES MOTOR: 8 countersunk socket head cap screws M10 x 18 mm (1) - 10,9 - DIN EN ISO 10642

ARES SPRING: 8 countersunk Allen screws M10 x 25 mm (1) - 10,9 - DIN EN ISO 10642



The M10 countersunk screws (1) - DIN EN ISO 10642 must be tightened to 40 Nm.

6.6.8. Installation of the arm lighting (retrofitting only)

When the system is delivered from the factory, the following options are fitted.




Fig. 39 Installation of indirect lighting module

The indirect lighting (9) of the extension arm (5) (lengths from 800 mm and 1000 mm for the XL model) is mounted on the upper part of the arm. Figure 39 shows a simplified representation with only the extension arm and spring arm (5) without pre-assembled cables.

- Remove the 3 sealing plugs (not illustrated) from the top of the extension arm and dispose of them in accordance with legal regulations.
- Pass the connection cable (4) of the basic holder with LED (3) through the mounting opening (5) to the extension arm without bending it.
- Place the cover (1) on the basic holder with LED (3) and screw it on with 2 countersunk head screws M4 x 16 mm (2) - DIN EN ISO 10642.
- Check that the extension arm lighting (9) is properly positioned and level with the extension arm, that the connection cable (4) is on the extension arm and that the screws are tightened securely.

6.6.9. Fitting of brake indicators (retrofitting only)

For the ARES INVERTED version, the extension arm lighting is mounted on the front of the upper arm (not shown).

When the system is delivered from the factory, the following options are fitted:




Fig. 40 Fitting the brake indicators

The figure shows an extension arm (5) with a spring arm (4). The installation procedure for the XL extension arm version with spring arm (4) is identical. The brake indicators (10) are mounted on the pivot or brake points of the arms.

Thus a double arm system incorporates 4 brake indicators (10), while the single arm version incorporates only 2.

- Gently unhook the 2 / 4 plastic covers ① on the 4 latches ②, remove them and store them in a safe place.
- Plug 1 connector of the power cable ③ into the connector plug ⑦ of the lighting board ⑤.

Colour code of the lighting boards ⑤: Upper bearing = green and Middle bearing = blue

- 3. Pass the power cord ③ through the hole ⑥ (see arrow) into the extension arm. Make sure that the plugs and the power cord ③ are not damaged and that the power cord ③ is fully seated in the extension arm.
- 4. Hook the illumination plate ⑤ from the bottom into the mounting opening ④ and carefully push it in until it audibly clicks into place, DO NOT push it in with force.
- 5. Check that the illumination plate ⑤ is correctly positioned, it must be seated in the mounting opening ④ without snapping into place.

NOTA

The colour code of the plastic covers ① shall be green for single arm systems and for double arm systems it shall be green on the top and blue on the bottom.

- 6. Gently push the 2 / 4 plastic covers ① into the mounting opening ④ until the 4 latches ② audibly click into place.
- 7. Check that the plastic covers ① are securely in place and are seated in the mounting opening ④ without snapping into place.
- 8. Place the service head (or CEMOR bracket if applicable) under the pendant system as described in the Service Head Installation Instructions.

6.7. Disassembly and assembly of covers

The main body of the ARES is supplied finished, so for on-site installation, the side walls and upper covers must be removed to be able to connect to the downpipes and, if necessary, to fit other accessory equipment (element trolleys).

NOTA

Only for orders where the service head does not come with the drop tube pre-assembled.

6.7.1. Disassembly and assembly of upper decks

- Using a flat-nosed tool and taking care not to damage the paint on the top covers, remove the bottom covers of the downpipes ①, these are press-fitted. See figure 41.

- Now move the upper covers of the main body ②, which are also press-fitted, by hand, first in the direction of the main body and, once the side wall has been cleared, by pulling them upwards. See figure 41.




Fig. 41 Removal of main body covers

- To reassemble these covers, carry out the above steps in reverse order.
- First attach the top covers ②. You will hear a sound when the clipping is done, slide it until it makes contact with the side wall. Check that the covers are securely fastened.
- Then fit the lower downpipe covers ① and press them in until you hear them click into place. Check that they are properly secured.

6.7.2. Disassembly and assembly of side walls

- Remove the top cover from the main body as described in section 6.7.1 of this manual.




Fig. 42 Disassembly/assembly of end caps on ARES main body

- Using a hexagonal tool, remove the 8 M4 x 6 screws ③ securing the 5 side flanges ② of the side wall ①, as shown in figure 42.

- Carefully remove the side panel ① and place it in a safe place.
- To reassemble the end caps, carry out the above steps in reverse order.
- First attach the end cap ① by supporting the side tabs ② in the threaded slots of the main body and secure it with the 8 M4 x 6 screws ③.
- Check that the side wall ① is properly fixed.

6.8. Service head assembly

Once the structural part has been fixed to the ceiling of the installation, the service head can be mounted. All the hoses for the electrical supply, for the supply and control of the brakes or motors (depending on the configuration of the suspended systems) and all the hoses for the supply of the different medical gas and/or vacuum systems are pre-assembled in the service head. It also includes a corrugated tube with a guide for the installation of the communications cables provided.

- Present the service head in front of the drop pipe of the system with the aid of the working platform.
- Route all electrical/voice and data cables and gas hoses pre-assembled in the service head through the arm/s system.



See section 6.9 of this manual.

Inside the service head are the spacers ①, M8 x 80mm threaded bolts ②, M8 hex nuts ③, S10 lock washers ④ and platens ⑤ required for fixing to the downpipes. See figure 43.




Fig. 43 Diagram of the anchoring of an ARES service head on a downspout

- Remove the lower downpipe covers and, if necessary, the upper main body covers as described in section 6.7.1 of this manual.



See section 6.7.1 of this manual.

- Remove the M8 hex nuts ③ ③ and S10 lock washers ④ and store them in a safe place.
- Fit the threaded bolts ② and use them to anchor the suspension chassis to the downpipe as shown in the picture on the left in figure 15, but do not tighten them completely.
- Make sure that the equipment is aligned and level. Then tighten the M8 nuts ③ ③ of all downpipes to a torque of 40 Nm.



The M8 hex nuts ③ must be tightened to 40 Nm.

- Finally, fit the previously removed covers to the main body following the steps described in section 6.6.1 of this manual.

6.9. Cable / tube and hose routing



Before any installation and adjustment work, the pendant system must be disconnected from the mains.

Damaged power cables can carry 230 V electrical voltage that energises the pendant system, and supply gases can escape from damaged supply hoses:

- Check all cables, tubes and hoses for damage. Be sure to insert them carefully without the cables/hoses crossing each other, without loops and without kinking.
- Cables and pipes must be positioned in the suspension system in such a way that they are not exposed to tensile stresses.
- Cables, pipes and hoses must be routed straight up out of the flange to prevent damage (e.g. chafing of the sheathing) and to allow free rotation.
- Protruding cables and hoses must not be routed in the service head or flanges, but must be routed in the interface plate and secured against falling with cable retainers.
- Electrical cables should be routed according to regional standards (in a spiral coiled tube if necessary).

NOTA

For systems with air brakes, check air supply lines and brake valves for contamination and clean if necessary.

- Cut the brake hoses, \varnothing 4 mm, flat-parallel.

- Brake lines and air supply lines must not be bent.
- Replace damaged or bent brake lines.
- The supply pressure of the air supply ducts at the installation site must be in the range of 4 to 6 bar. The optimum operating pressure is 5 bar.

Power cables, pneumatic lines, earthing and control cables as well as gas hoses are pre-installed in the service head and must be routed through the pendant system. Order-specific cables, including telephone and nurse call cables, must be routed separately through the pendant system.

6.9.1. Preparation of supply lines for CEILING FIXED ARES

In order to install a service head on a CEILING FIXED ARES unit, the supply lines to the unit must be prepared, which previously had to be routed through the roof pipe. As this variant has no movement, the gas supply must be carried out with copper piping.




Fig. 44 Preparation of supply lines

Damaged power cables can carry 230 V electrical voltage that energises the pendant system, and supply gases can escape from damaged supply hoses:

- Check all cables, tubes and hoses for damage. Be sure to insert them carefully without the cables/hoses crossing each other, without loops and without kinking.
- Cables and pipes must be positioned in the suspension system in such a way that they are not exposed to tensile stresses.

- Cables, pipes and hoses must be routed straight up out of the flange to prevent damage (e.g. chafing of the sheathing) and to allow free rotation.
- Protruding cables and hoses must not be routed in the service head or flanges, but must be routed in the interface plate and secured against falling with cable retainers.
- Electrical cables should be routed according to regional standards (in a spiral coiled tube if necessary).

NOTA

For systems with air brakes, check air supply lines and brake valves for contamination and clean if necessary.

- Cut the brake hoses, \varnothing 4 mm, flat-parallel.
- Brake lines and air supply lines must not be bent.
- Replace damaged or bent brake lines.
- The supply pressure of the air supply ducts at the installation site must be in the range of 4 to 6 bar. The optimum operating pressure is 5 bar.

Power cables, pneumatic lines, earthing and control cables as well as gas hoses are pre-installed in the service head and must be routed through the pendant system. Order-specific cables, including telephone and nurse call cables, must be routed separately through the pendant system.

6.9.2. Connection of pneumatic brakes




Fig. 45 Routing of brake air hoses. Colour coding




Fig. 46 Routing the air hoses for the brakes. Connection.

The pneumatic brake hoses ① are pre-mounted on the suspension system and connected to the brake connection points (1) and (2). If necessary, the brake hoses ① are fitted in the form of a spiral tube.

The pneumatic supply line must be depressurised:

- To install the brake hoses, push them into the brake connection point. If the brake pipe is correctly positioned, it can no longer be removed from the brake connection point.
- To disengage the brake hoses at the connector ② press the release mechanism ③ and then remove the brake hoses.
- Plug the air supply hose (BLACK mark) into the connector ② (BLACK mark).
- Plug the brake hose (GREEN marking) into the connector ② (GREEN marking).
- Plug the brake hose (BLUE marking) into connector ② (BLUE marking).
- Connect the air supply hose and the 2 brake hoses ① to the plug connector as described in the Service Head Installation Instructions.
- The brake tubes ① may be too long depending on the installation position of the rack. If this is the case, cut the brake hoses ① to length.




Fig. 47 Routing of the air brake power cable

- Route the power cable ① (in a spiral coiled tube if necessary) through the pendant system and into the interface plate as shown in Figure 47.
- Perform a functional test as soon as the service head is fully installed:
- Press the green brake button A. The brake on the upper extension arm should release.
- Press the blue brake button B. The brake on the lower extension arm should release.

6.9.3. Connection of supply and management circuits for electromagnetic or motor brakes

Cables, copper tubes and supply hoses are pre-assembled by Tedisel. All connections for the management of the electromagnetic brakes and/or motors are pre-assembled on the service head.

NOTA

For the ARES INVERTED version, the cables are routed upwards through the front upper extension arm (not illustrated).

The following figure illustrates the connection of the electromagnetic brakes in a double arm system. For the single arm case the connection between the service head and the drop tube output cables are connected in the same way, in this case there will only be one supply line to the interface board as there is only one brake.




Fig. 48 Connection of earthing cables

- Check that the connection cables are fitted with the plugs ④/⑤ and ⑭/⑮ between the power supply unit ① and the distributor board ③. If missing, fit the connection cables included in the packaging with the plugs ④/⑤ and ⑭/⑮ as shown in the figure.
- Connect the upper brake by establishing the mounting connection ⑫ between the cable ⑪ and the extension cable ⑩ via the release mechanism as described in point 6.6.3 of this manual.
- Plug the connector of the extension cable ⑩ into the corresponding distribution board socket ③ as illustrated in the figure.
- Connect the lower brake by plugging the cable connector ⑥ into the socket on the corresponding distribution board ③ as shown in the figure.
- Establish the mounting connection ⑧ of the control cable ⑦ of the service head with the control cable ⑨ by retrieving the control cable ⑨ that is coiled at the highest point of the drop tube.
- Plug the power cable ⑬ included in the scope of delivery into the socket on the corresponding distribution board ③ and pass it through the extension arm to the interface board as shown in the figure.
- If required, Tedisel can provide a circuit diagram/wiring diagram.

Nº in Fig	From	To	Disengagement	Length [mm]	Observation
⑥	Bearing unit	Distributor board	-	100	Integrated in the bearing unit
⑦	Faceplate	Drop tube	Service head socket / distributor board		Integrated in service head
⑨	Distributor board	Service head	Cable card / service head	2600	-
⑩	Bearing point 1	Distributor board	Brake cable 1 / Distributor plate	1100 - 1500	Arm length 600/800 - 1000/1200
⑪	Bearing unit	Cable ⑩, distribution	-	100	Integrated in bearing unit
⑬	Network connection	Distributor board	Mains cable / Distribution board	5000	-

Table 1. Cable assignment of the pendant system, double arm variant

6.9.4. Connection of the earthing cables to the support arm

The earthing cables are pre-assembled on the extension arm and must be routed and connected in the direction of the arrow.

- Route and connect the grounding wires in the direction of the arrow shown in the figure and, if necessary, route them towards the interface board.
- Route the mounted grounding wires ① from the flange along the roof tube to the interface plate.
- Route the grounding wires ② out of the service head through the pendant system and into the interface plate.




Fig. 49 Connection of earthing cables

6.9.5. Laying of power cables and hoses through the support arm

Power cables and gas hoses are pre-assembled in the Service Head. Order-specific cables, including telephone and nurse call cables, must be routed separately through the pendant system.

- Carefully route the power cables and hoses ① through the pendant system and onto the interface plate:




Fig. 50 Laying of the supply cables and hoses through the suspension system

- Then guide the service head without putting any strain on the supply cables and hoses ①.
- Make sure that the cables laid are not damaged or torn out.
- Pass the order-specific cables (nurse call, telephone, etc.) through the pendant system.
- Mount the service head on the pendant system.



See section 6.8 of this manual

6.9.6. Installation of gas hoses and air exhaust ducts

- Ensure that gas types are correctly assigned

The gas type is indicated by colour on the gas supply hoses. These hoses are fitted with a sealing plug which can only be removed during installation.

- Check hoses and lines for dirt and clean them with oil-free air.
- Ensure that cables, hoses and conduits are assigned to the correct supply outlets.




Fig. 51 Example of connection of gas hoses and anaesthesia gas evacuation systems

Check the gas supply hoses for contamination and clean them with oil-free air.

- Attach a hose clamp to the gas supply hose, remove the sealing plug and push the hose into the correct gas supply outlet.
- Up to 3 gas supply hoses and up to 2 vacuum hoses can be connected to one gas valve using Y-connectors.
- Press on the hose clamp and check that it is securely in place.
- Connect and secure the anaesthetic gas suction hoses and the air motor exhaust air hoses.
- Perform a gas type test by following these 5 points:
 1. gas outlets and marking according to EN ISO 9170-1 or EN ISO 9170-2
 2. Leakage according to EN ISO 11197
 3. Congestion according to EN ISO 7396-1 or EN ISO 7396-2

4. Solid contamination according to EN ISO 7396-1 or EN ISO 7396-2

5. Gas type according to EN ISO 7396-1 or EN ISO 7396-2

6.9.7. Connection of the different electrical circuits

Figure 52 shows a simplified illustration of the interface board (1) without extension arm and cables, etc. Wiring shall always start with the equipment grounding wires.



Before any installation and adjustment work, the pendant system must be disconnected from the mains.

- Cut all green/yellow earthing wires (2.5 mm² and 10 mm²) to the correct length.




Fig. 52 Connection of the earthing cables on the interface board

- Pass the grounding wires through the strain relief mechanism and connect them to the 4 mm² or 10 mm² series terminals on the grounding terminal block (1) on interface board 1.
- All earthing cables must be securely installed in the strain relief mechanisms (2).




Fig. 53 Connection of the power supply cables on the interface board

Figure 53 shows a simplified illustration of the interface board 1 without extension arm and cables, etc.



Before any installation and adjustment work, the pendant system must be disconnected from the mains.

- Pass all power wires through the strain relief mechanism ① and connect them to the terminal block ② as illustrated in the wiring diagram provided at the installation site.
- All power cables must be securely installed in the strain relief mechanisms ①.
- Carefully check that the power cables are not trapped or bent during the entire rotational movement of the extension arms.

6.9.8. Extension arm lighting connection (optional)




Fig. 54 Connection of optional accessories to the support arm, double arm variant

- Establish the mounting connection ② between the cable ① and the extension arm lighting with the extension cable ③ included in the packaging.

NOTA

Only for modifications to an already installed product, if the product is delivered with the factory option, the mounting connection ② has already been made.

- Route the extension cable ③ through the extension arm and out of the console tube.

- Establish the mounting connection ④ between the extension cable ③ and the control cable ⑤ routed outside the service head.

6.10. Fitting of trims

6.10.1. Fitting of a single / double trim

The figure shows a simplified illustration of the interface board without cables and without the extension arm.

- Screw the M10 hex nuts ① onto the M10 x 360 mm threaded bolts ②.
- Screw the M10 x 360 mm threaded bolts ② into the interface plate (1) in such a way that the canopy halves mounted below are flush with the suspended ceiling.

If an interface plate (1) is mounted directly to the forging, the threaded bolts M10 x 360 mm ② must be cut to length.




Fig. 55 Preparation of the installation



The 4 M10 hex nuts ① must be tightened to 46Nm.

- The M10 x 360 mm threaded bolts ② must be mounted at the same distance from the interface plate 1.




Fig. 56 Fitting the trim halves

- Place the sectional strip (not shown in the figure) on the first half of the trim (2) as shown in figure 56 (optionally, the canopy can be sealed with silicone).
- Fit the first half of the trim (2) onto the M10 x 360 mm threaded bolts (1) and then screw on and tighten the cover screws (3).
- Check that the trim half (2) is flush with the false ceiling. If necessary, refit the 6 threaded bolts M10 x 360 mm (1).
- Place the section rail (not shown) over the second half of the bonnet (4) and push it onto the first half of the trim (2) so that they fit tightly together.
- Fit the second half of the trim (4) onto the M10 x 360 mm threaded bolts (1) and then screw on and tighten the 3 cover screws (3).

6.10.2. Fitting of protective covers. Covers

6.10.2.1. Assembly/disassembly of protective caps on an extension arm

The figure shows a device with extension arm and with motor arm (5). The installation procedure for the XL extension arm version (5) with motor arm or spring arm is identical. A simplified representation is shown with only the extension arm without cables. The detailed representation shows a sectional view of the cover (1).




Fig. 57 Assembly (left) / disassembly (right) of protective caps on an extension arm

- Place the protective cap ① on the end of the extension arm (5) and ensure that the retaining clip ② is seated in the opening ④.
- Push the cover ① onto the extension arm (5) as far as it will go and make sure that the latch ③ fits into the slot ⑤. Make sure that the cables are not damaged.
- If correctly mounted, the cover ① can no longer be removed from the extension arm (5).
- Check that the cover cap ① is absolutely at the same height as the extension arm (5).
- To remove the protective cover ①, insert a small flat screwdriver between the protective cover ① and the extension arm (5) and gently push the latch ② out of the slot ④. Make sure not to damage the paint on the extension arm, the latch ② and the protective cover ①.
- Pull the cover ① backwards until the retaining clip ③ no longer engages and the cover ① can move freely. Do not twist the cover ① and do not remove it with force.
- Remove the protective cap ① upwards and store it in a safe place.

6.10.2.2. Mounting of rear and front covers on a motor or spring arm

The figure shows the motor arm (4). The installation procedure for the extension arm (5) with motor arm (4) or the XL extension arm (5) with motor arm (4) is identical. The figure shows a simplified representation with only the motor arm (4) without cables.

If the front cover is confused with the back cover or vice versa, there is a risk that the covers will be damaged and become unusable.

NOTA




Fig. 58 Mounting of rear and front protective covers on a spring or motor arm

- For a motorised arm, observe the cover plate positions indicated in the description below.
- Fit the 2 halves of the rear protective cover ① (motor or spring side), see the 2 cut-outs ②, around the motor/spring arm (4).
- For a motorised arm, the upper and lower protection covers do not have the same construction. In addition, the lower protection cover is easily distinguishable due to its rounded corners ③.
- To ensure that the protective cover halves ① fit securely in place, place them inside each other in the correct position ⑤ illustrated in the figure and then glue them in the direction of the arrow. The protective cover halves fit together and are connected.
- Check that all latches of the protective cover halves ① are securely latched together.
- To fit the front covers ④ repeat the procedure (without cutting ②).

6.10.2.3. Mounting of rear side covers on a motor or spring arm

The figure shows the motor arm (4). The installation procedure for the extension arm (5) with motor arm (4) or the XL extension arm (5) with motor arm (4) is identical. The figure shows a simplified representation with only the motor arm (4) without cables.




Fig. 59 Mounting of the rear side covers on a motor arm (left) or spring arm (right)

- Fit the first side cover ① and insert 3 plastic pins ③ into the holes ② in the motor arm. Make sure that the protective cover ⑥ protrudes through the guide ⑤ of the first side cover ①.

- Fit the second side cover and insert 3 plastic pins (3) into the holes (2) in the motor arm (4).
- The protective cover (6) must protrude into the guide (5) of the side cover panel (1) and the 3 locking devices (4) on the two side covers must engage with each other.
- The side covers must fit tightly together without gaps.

6.10.2.4. Rear bottom cover mounting on a motor or spring arm

The figure shows the motor arm (4). The installation procedure for the extension arm (5) with motor arm (4) or the XL extension arm (5) with motor arm (4) is identical. The figure shows a simplified representation with only the motor arm (4) without cables.




Fig. 60 Mounting of the lower rear cover on a spring or motor arm

- Hold the rear bottom cover (2) at the angle shown in the figure.
- Insert the gasket (4) of the rear bottom cover (2) into the 2 mounting devices (3) of the side covers (1).
- Lift the rear bottom cover (2) so that the 2 latches (5) snap into place.
- Check that the cover (2) is securely in place by verifying that it sits on the side covers (1) without gaps.
- For arm with motor. Insert 2 M3 x 10 mm countersunk Allen screws (7) into the openings (8) of the cover (2) and tighten them.

6.10.2.5. Mounting of front side covers on a motor or spring arm

The figure shows the motor arm (4). The installation procedure for the extension arm (5) with motor arm (4) or the XL extension arm (5) with motor arm (4) is identical. The figure shows a simplified representation with only the motor arm (4) without cables.




Fig. 61 Mounting the front side covers on a spring or motor arm

- Fit the right-hand side cover ① and insert 2 plastic pins ⑤ into the holes ⑥ in the motor arm (4).
- Make sure that the cover ④ protrudes into the guide (not shown in the figure) of the side cover ①.
- Attach the left side cover ③ to the mounting fitting ② on the front of the right side cover ①, direct it to the motor arm (4) and then insert 2 plastic pins ⑤ into the holes ⑥ in the motor arm (4).
- Make sure that the cover ④ protrudes into the guide (not shown in the figure) of the side cover ③.
- Gently push the 2 straps ⑦ into the bottom of the side covers and hook them together.
- The side covers must fit tightly together without gaps.

6.10.2.6. Mounting of front top cover on a motor or spring arm

The figure shows the motor arm (4). The installation procedure for the extension arm (5) with motor arm (4) or the XL extension arm (5) with motor arm (4) is identical. The figure shows a simplified representation with only the motor arm (4) without cables.




Fig. 62 Mounting of the front top cover on a spring or drive arm

- Position the front top cover ① from above and attach one of the 2 shafts ④ to the mounting device ⑤ of the side cover.
- Carefully detach the front top cover ① and attach the second shaft ④ to the mounting device ⑤ of the side cover.
- Lower the cover ① until the 2 latches ② snap into place.
- The front top cover ① must sit on the side covers without gaps.

6.11. Mounting of a trolley (optional)

This section shows the assembly of a trolley. This element does not come pre-assembled, it must be installed once the main body has been installed in the room where it is to be used.

- Remove the side wall as described in section 6.6.1 of this manual.
- Position the first carriage limit switch (the one furthest from the head end) as described in section 6.10.2 of this manual.

- Insert the carriage with the bearings ② into the guide in the centre of the main body ① as shown in figure 63.




Fig. 63 Assembly of the trolley

- Fit the second limit switch as described in section 6.10.2 of this manual.
- Refit the side wall as described in section 6.6.2 of this manual.

6.12. Adjustments



Disconnect the equipment electrically, as well as any equipment supplied through the service head, before making adjustments to prevent live system cables leading to the equipment from coming into contact with live parts of the system.

6.12.1. Adjustment of the mechanical brake on the arms

In case of failure of the pneumatic (compressed air operated) brakes, additional mechanical brakes (friction brakes) keep the extension arm and motor arm stable. Adjust the braking force in such a way that the motor arm or extension arm remains stable in any position and can still be adjusted conveniently.




Fig.64 Friction brake adjustment

The mechanical brakes (friction brakes) hold the extension arm (2) in any set position. Adjust the braking force in such a way that the extension arm (2) remains stable in any position and can still be adjusted conveniently.



Risk of collision. If the brakes are not correctly adjusted, the extension arm may automatically move in an uncontrolled manner.

NOTA

Observe the end stop recommendation in chapter 6 and make sure to tighten the brake bolts of the Unit on the roof tube more than at the bearing point of the lower extension arm. This facilitates the bending of the lower extension arm and allows the bearing unit on the lower extension arm to rotate freely.



See section 6.12.4 of this manual.

Use a suitable torque spanner to adjust the brake.

- To increase the braking force, tighten the slotted brake screws (1) by turning them evenly to the right (clockwise). Tighten to 1.6 Nm.
- To reduce the braking force, unscrew the slotted brake screws (1) by turning them evenly to the left (counterclockwise).
- Carrying out a test run

6.12.2. Adjustment of the mechanical brake on the drop tube (with bearing)

The brake screw (friction brake) is adjusted in the same way for all different versions of the suspension system. Adjust the braking force of the respective end device so that the end device remains stable in any set position and can still be adjusted comfortably. In the figure below you can see the adjustment scheme for the service head.




Fig.65 Friction brake adjustment on drop tube with bearing

Use a suitable flat-blade screwdriver.

- To increase the braking force, insert the flat screwdriver into the brake screws (1) and turn it clockwise to the right.
- To reduce the braking force, insert the flat screwdriver into the brake screws (1) and turn it to the left (counterclockwise).

- Carry out a test run.

6.12.3. Adjustment of the mechanical brake on the drop tube (with bearing)

The brake screws (friction brakes) are adjusted in the same way for all different versions of the suspension system. In the case of the drop tube with friction bearing unit, the mechanical brakes (1) (3 friction brakes) hold the end device (e.g. the service head) in the set position. Adjust the braking force in such a way that the corresponding end device (e.g. service head) remains stable in any set position and can still be adjusted comfortably.




Fig.66 Friction brake adjustment on drop tube with bearing

Use a suitable torque spanner to adjust the brake.

- To increase the braking force, tighten the slotted brake screws (1) by turning them evenly to the right (clockwise). Tighten to 1.6 Nm.
- To reduce the braking force, unscrew the slotted brake screws (1) by turning them evenly to the left (counterclockwise).
- Carrying out a test run

6.12.4. Adjustment of the rotary stops

The extension arm and drop tube are equipped with at least 1 ball stop that prevents the internal cables from being destroyed. With 1 ball stop installed, the swivel range is restricted to a maximum of 340 degrees. With 2 ball stops installed, the swivel range can be further restricted.

NOTA

For the version with an inverted arm, 2 ball stops must always be mounted between the

extension arms to prevent the extension arms from hitting each other.




Fig.67 Adjustment of the rotary stops

The swivel ranges of the drop tube and arm versions are different:

- For versions with low load capacity adjust the swivel range of the upper and lower extension arms in increments of 22.5 degrees. Use one M16 fixing screw and two \varnothing 12.7 mm ball stops for each extension arm or motorised arm.
- For versions with medium load capacity set the swivel range of the upper extension arm to 15.0 degree graduations and the swivel range of the lower extension arm to 22.5 degree graduations. Use 1 M20 fixing screw and 2 ball stops \varnothing 16 mm for the upper extension arm. Use 1 M16 set screw and 2 ball stops \varnothing 12.7 mm for the lower extension arm.
- For high load capacity versions, set the swivel range of the upper and lower arms in 15.0 degree increments. Use 1 M20 fixing screw and 2 ball stops \varnothing 16 mm for each arm.

- For versions with pneumatic and friction brake adjust the swivel range of the upper and lower extension arms in 15.0 degree increments. Use 1 M16 fixing screw and 2 ball stops \varnothing 10 mm for each extension arm.
- For versions with drop tube with friction bearing unit (roller bearing) set the swivel range of the console tube in increments of 15.0 degrees. Use 1 M16 fixing screw and 2 ball stops \varnothing 10 mm for each drop tube.
- For versions with electromagnetically braked drop tube, set the swivel range of the bracket tube in increments of 22.5 degrees. Use 1 M16 fixing screw and 2 ball stops \varnothing 12.7 mm for each drop tube.

NOTA

A magnetic pin or similar tool is required to displace the ball stop. Telescopic magnet pick-up tool kit is available as an option.

- For versions with double arm and friction bearing in between, it is recommended to fit 2 ball stops (3) (see Fig. 68). The detailed illustration shows the intermediate bearing (11) (without outer ring) and the position of the stop screw (1) in the ball stops (3).




Fig.68 Double double arm system and friction bearing between arms

When adjusting the end stop as illustrated in Figure 68, the dead centre area is 45° . This means that the spring arm (3) has a maximum range of movement of approx. 315° . If the minimum setting on the end stop is not defined while adjusting the brakes on the intermediate bearing (11) and the ceiling bearing (10), it is quite difficult to bend the suspension system from the stretched position (12) and turn it on the intermediate bearing (11) of the spring arm (3).

When moving the adapter on the drop tube (4) from the extended position (12), there is a risk that the extension arm and spring arm will rotate around the ceiling bearing (10) although it would be desirable to bend in the area of the intermediate bearing (11).

6.12.5. Replacement or disassembly of the rotary stops

The following section describes how to adjust the end stop on the drop tube with friction bearing unit (roller bearing) and on the arms. The procedure for adjusting the end stop is identical for the drop tube with electromagnetic brake unit.




Fig.69 Removing the rotary stops

- Unscrew the fixing screw (1) from the threaded hole (2).
- Rotate the drop arm or drop tube until the ball stop (3) is visible in the threaded hole (2).
- Using a telescopic magnet pick-up tool, remove the ball stop (3) from the threaded hole (2) and store it in a safe place.

6.12.6. Assembly of the rotary stops

NOTA

For the inverted arm version, the ball stops must always be mounted between the extension arms to prevent the extension arms from hitting each other.




Fig.70 Assembly of the rotary stops

- Rotate the extension arm or console tube to the desired end stop position and then insert 1 ball stop (3) into the threaded hole (2).
- Ensure that the ball stop is firmly in place. The extension arm or drop tube can be rotated once the ball stop (3) has been fully inserted into one of the mounting fittings (4). Otherwise, these lock and the ball stop (3) must be pushed into one of the mounting fittings (4) while gently turning the extension arm or drop tube with a screwdriver.
- Rotate the extension arm or console tube to the desired position of the second end stop and then insert 1 additional ball stop (3) into the threaded hole (2).
- Slightly rotate the extension arm or drop tube and then screw the set screw (1) into the threaded hole (2) as far as it will go. The set screw (1) now serves as an end stop for the mounted ball stop (3) and restricts the swivel range of the extension arm or drop tube.
- Tighten the set screw (1) to 40 Nm.
- To check that the swivel stop is working properly the swivel range of the extension arm or drop tube must be limited to less than 360 degrees.

6.12.7. Vertical lift adjustment on the engine arm

The simplified representation illustrates the extension arm and motor arm without the cables mounted. The adjustment is identical for all versions. The motor arm has a vertical lift of + 20 degrees in the upward direction and - 30 degrees in the downward direction. The vertical lift can be restricted in both up and down direction.




Fig.71 Opening of the lower rear cover and component details

- To adjust the height of the motor arm, the end stop ⑧ on the ball screw nut ⑨ is directed towards the 2 upper end switches ⑤/⑥ and 2 lower end switches ⑩/⑪ which switch off the motor.
- The end switch ⑥ or ⑩ actuated first by the end stop ⑧ ensures decelerated starting or braking (SoftStart / SoftStop) of the motor.
- The second limit switch ⑤ or ⑪ switches the engine off.
- The upper and lower vertical lifts are adjusted separately and one after the other. To adjust the vertical lift, move the motor arm to the desired upper or lower height position.



Disconnect all poles of the pendant system from the mains and prevent it from being switched on again.

- Use an Allen key (size 2.5) and unscrew 2 M4 x 6 mm countersunk Allen screws ⑦ - ISO 7380 - 10.9.
- Push the circuit board with the end switches ⑤/⑥ towards the end stop ⑧ until the end switch ⑤ or ⑪ audibly engages and then tighten the 2 M4 x 6 mm countersunk Allen screws ⑦ - ISO 7380 - 10.9.



If the motor arm moves without a properly installed limit switch, the motor arm may be damaged and must be replaced.

The vertical lift adjustment may change gradually during operation if the M4 x 6 mm countersunk Allen screws ⑦ - ISO 7380 - 10.9 have not been tightened correctly. In this case, there is a risk of the motor arm hitting the ceiling or other hanging system.



Tighten the M4 x 6 mm countersunk Allen screws ⑦ to 3 Nm.

- Close the lower rear cover ④ as described in the following section and perform a function test.
- Repeat these steps for limit switches ⑩/⑪ if necessary.

6.12.7.1. Opening / closing of the lower rear cover

To open the lower rear cover, use an Allen key (size 2).

- Unscrew the 2 M3 x 10 mm countersunk Allen screws ① from the 2 openings ③.
- Release the 2 latches ②.

- Manually direct the lower rear cover ④ all the way down until it points downwards in a completely vertical position.
- To remove the cover ④, turn it approx. 45 degrees downwards.
- Be sure to pass this position before releasing the cover ④.

To close the rear bottom cover, push it back in until the 2 latches ② snap into place.

- Check that the cover ④ sits on the side covers without gaps.
- Insert the 2 M3 x 10 mm countersunk Allen screws ① into the 2 openings ③ in the cover ④ and tighten them.

6.12.8. Correcting the vertical alignment of the Service Head on a power arm

After mounting an end device (e.g. medical device, etc.), it may be necessary to vertically align this end device.




Fig.72 Adjusting the load capacity of the motor arm and closing the rear bottom cover

- Open the lower back cover as described in 6.10.7.1 above.
- Use an Allen key (size 4) and a spanner (size 36).
- Loosen the M4 set screw ⑦ - DIN 914 using the Allen key.
- Place the spanner on the hexagonal bolt ⑤.

- The indicator screw ⑥ points downwards (do not loosen this screw).
- To lower the tray in the example shown in Fig. 72, turn the hexagonal bolt ⑤ so that the indicator screw ⑥ points forwards (towards you). See Fig. 72 Detail view, bottom right.
- To lift the tray in the example shown in Fig. 72, turn the hexagonal bolt ⑤ so that the indicator screw ⑥ points backwards (away from you). See Fig. 72 Detail view, bottom right.
- Carry out a test run.
- Tighten the M4 grub screw ⑦ - DIN 914.

The vertical alignment can change progressively during use if the M4 fixing screw ⑦ - DIN 914 has not been tightened correctly. If this happens, the CEMOR service head or monitor bracket no longer remains stable in its adjusted position.



Tighten the M4 set screw ⑦ - DIN 914 to 2 Nm.

- Close the lower rear cover as described in 6.10.7.1 above.

6.12.9. Adjusting the load capacity on the spring arm

The simplified representation illustrates the extension arm and the spring arm without the cables mounted. The adjustment is identical for all versions. The spring arm is equipped with 1 or 2 springs which compensate the weight of the CEMOR or the service head with the end device (e.g. flat screen, medical device, etc.).




Fig.73 Adjusting the load capacity of the spring arm and the rear bottom cover lock

Adjust the load capacity of the spring arm so that the spring arm with service head or CEMOR monitor holder and the end device (e.g. flat screen, medical device, etc.) remain stationary in any set position.

NOTA

If the spring arm does not remain in position after adjusting the spring tension, the spring arm must be replaced by a service technician.

Possible versions of spring-loaded equipment: 30-60 kg, 50-80 kg, 70-110 kg, 80-135 kg, 120-180 kg.

The load capacity ranges and the maximum load capacity are indicated on the spring arm nameplate.

- Use an Allen key (size 10) and a ring spanner (size 24).

- Unscrew the socket head cap screw M8 x 16 mm ⑤ - DIN 7984 with the ring spanner.
- Insert the Allen key into the set screw ④.
- Raise the spring arm approx. 10 degrees above horizontal (0 degree position) to relieve the tension on the adjusting screw ④.
- If the spring arm moves downwards, the load capacity is too low.
- Turn the Allen key to the left (counterclockwise) as illustrated in the figure.
- If the spring arm moves upwards, the load capacity is too high.
- Turn the Allen key to the right (clockwise) as shown in the figure.
- Carry out a test run.
- Screw in and tighten the socket head cap screw M8 x 16 mm ⑤ - DIN 7984 with the ring spanner.

The setting of the load capacity can change progressively during operation if the socket head cap screw M8 x 16 mm ⑤ - DIN 7984 has not been tightened correctly. If this is the case, the spring arm no longer remains stable in its set position.



Tighten the M8 x 16 mm Allen screws ⑤ to 12 Nm.

6.12.9.1. Opening / closing of the lower rear cover

To open the lower rear cover

- Insert a suitable screwdriver into the 2 openings ② one after the other and then release the 2 latches ①.
- Fold down the rear bottom cover ③.

To close the rear bottom cover, push it back in until the 2 latches ① snap into place.

- Check that the cover ③ sits on the side covers without gaps.

6.12.10. Adjusting vertical lift on a spring arm

When replacing an end device (e.g. flat panel display, medical device, etc.), the spring arm must be adjusted to a horizontal position (0 degree position).




Fig.74 Adjusting the vertical lift on a spring arm

- Use an Allen key (size 10) and a ring spanner (size 18).
- Loosen and turn back the M12 hexagon nut (4) - ISO 4035.
- Insert the Allen key into the set screw (5).
- To reduce the vertical lift, turn the Allen key to the left (counterclockwise) as illustrated in Figure 74.
- To increase the vertical lift, turn the Allen key to the right (clockwise) as illustrated in Figure 74.
- Carry out a test run.
- Tighten the hexagon nut M12 (4) - ISO 4035.

The vertical lift may change progressively during operation if the M12 hexagon nut (4) - ISO 4035 has not been tightened correctly. In this case,



If the M12 hexagon nut (4) - ISO 4035 has not been tightened correctly, there is a risk that the spring arm will hit the ceiling or another suspension system.



Tighten the hexagon nut M12 (4) - ISO 4035 to a torque of 30 Nm.

6.12.10.1. Opening/closing of the front top cover

- To open the front top cover insert a suitable screwdriver into the 2 openings ② one after the other and then release the 2 latches ①.
- Lift the front top cover ③ until it clicks into place.
- To close the front top cover, fold down the front top cover ③ so that the 2 latches ① snap into place.
- Check that the cover ③ sits on the side panels without gaps.

6.12.11. Vertical alignment correction

After mounting an end device (e.g. flat screen, medical device, etc.) there is a risk that the service head or the CEMOR monitor holder is no longer in an exactly vertical position due to the weight of the end device.




Fig.75 Correcting the vertical alignment of the CEMOR service head or monitor bracket

- Open the lower rear cover as described in 6.10.9.1 above.
- Use an Allen key (size 4) and a spanner (size 36).
- Loosen the M4 fixing screw ⑥ - DIN 914.
- Place the spanner on the hexagonal bolt ④.

- The indicator screw ⑤ points downwards (do not loosen this screw).
- To lower the tray in the example shown in figure 64, turn the hexagonal bolt ④ so that the indicator screw ⑤ points forwards (towards you).
- To lift the tray in the example shown in Figure 64, turn the hexagonal bolt ④ so that the indicator screw ⑤ points backwards (away from you).
- Carry out a test run.
- Tighten the M4 grub screw ⑥ - DIN 914.

The vertical alignment can change progressively during use if the M4 fixing screw ⑥ - DIN 914 has not been tightened correctly. If this happens, the CEMOR service head or monitor bracket no longer remains stable in its adjusted position.



Tighten the M4 set screw ⑥ - DIN 914 to 2 Nm.

- Close the lower back cover as described in 6.10.9.1 above.

6.13. Limit switch adjustment for element carriages

The trolleys of ARES equipment can slide freely over the entire length of the service head on which they are installed. It is necessary to limit their travel to ensure that these elements do not conflict with operator space or other elements. See figure 76 and 77.




Fig.76 Adjusting the travel limit switches.

- Use an Allen key to loosen the bolt ② of the cross stop ①.
- Move the cross stop to the desired position on the service head guide.

The example in figure 77 shows an ARES unit with two element carriages, the limit switches must ensure that the element carriages do not collide with the other elements in the environment.




Fig.77 Adjusting the travel limit switches. Maximum stroke

- Tighten the Allen stud ② and check that the cross stop is fixed in this position.
- Do the same with the second crosscut fence.



The hexagon socket bolts ② M8 - DIN 913 must be tightened to 40 Nm.

7. Installation checks

When making adjustments to the equipment, it is necessary:

- verify that the relevant medical gas shut-off valves are properly closed and ensure that the system cannot be reopened.
- verify that the system is electrically disconnected, and measures must be taken to ensure that the system cannot be reconnected.



CAUTION: Failure to comply with this point will cause serious damage.



Before any installation and adjustment work, the pendant system must be disconnected from the mains.

7.1. Check the technical characteristics of the equipment to be installed. Weights, torques.

Before proceeding with the installation of the equipment, it must be checked that the surface on which the equipment is to be installed meets the space and resistance requirements according to the characteristics of the equipment in question.



See point 6 of the user and cleaning manual supplied with the equipment.

7.2. Check the condition of the cables and hoses in the system and the rotation of the arms.

Before installing the equipment, check that the cables and hoses of the system are not strained or kinked. There is a risk of destroying or damaging the extension arm cables if an extension arm is rotated more than 360 degrees:

- Do not rotate the extension arms more than 350 degrees.
- If necessary, limit the swing range of the arms.



See section 6.12.4 of this manual.

The system is supplied as standard with the 2 ball stops ② and the fixing screw ① pre-assembled. The swivel range of the arm (4) or the arm (5) is limited to 0 degrees. This ensures that the arms cannot rotate and that the internal power cables are not broken.




Fig. 78 Swivel stop status

In exceptional cases, the 2 ball stops ② and the set screw ① are delivered as separate components, which means that the arm (4) or the arm (5) can be rotated infinitely more than 360 degrees.



At least 1 ball stopper must be fitted to prevent the internal power cables from twisting.

If no swivel stops have been pre-mounted, the arm (4) and/or the arm (5) must not be swivelled before the swivel stops have been mounted.

- Mount at least 1 ball stop as described in Chapter 6.10.5 to restrict the rotation angle of the arm (4) and/or the arm (5) to 340 degrees.

To adjust the rotary stops



See section 6.12.4 and section 6.12.5 of this manual.

7.1. Mechanical test

It must be checked that each of the anchorage points is properly fixed to the mounting surface and that there is no displacement of the equipment.



WARNING: Personal injury may result from dropping the equipment.



See section 6.6.5 of this manual.

7.2. Check service head enclosure.

Check that each element of the service head enclosure that has been removed for the installation operations described in this manual is properly fixed and secured in its intended position.

- Checking of openings, closings, foldings, displacements.



See section 6.7 of this manual



WARNING: The use of gloves is recommended as minor personal injury may occur.

7.3. Mechanical crash test

Once the system has been installed, it must be checked to ensure that no collisions can occur with:

- other hanging systems,
- ceilings or walls,
- other equipment

7.4. Gas circuit test.

The equipment must be tested according to the current standards, EN ISO 7396-1_2016 and EN ISO 7396-2_2007 by qualified personnel.

The medical gas piping system shall be checked:

- Watertightness
- Integrity
- No crossovers between circuits.
- Good functioning of the gas intakes

These tests shall be carried out at operating pressure.



CAUTION: Danger of impact of a metallic element due to faulty disconnection, can cause serious personal injury.

7.5. Electrical circuit tests.

Once the equipment has been installed, power must be supplied to each of the circuits provided and a test must be carried out to check that all the mechanisms provided in the circuit in question, and only these, are supplied with voltage.

- Check continuity of protective earth wiring.



DANGEROUS VOLTAGE: To avoid the risk of electric shock, equipment must be connected to a protective earth. Failure to do so may result in personal injury.

8. Regulations

8.1. Team ranking

According to the new **MDD** regulation **93/42/EEC** concerning medical devices, this product family is classified as:

- Class IIb, by Annex II, excluding section 4, regulation 11.
- Protection level IP20 according to IEC 60529

Equipment intended for continuous operation.

8.2. Reference standards

The device complies with the safety requirements of the following standards and directives:

ISO11197: Medical supply units

IEC 60601-1: Medical electrical equipment. General requirements for basic safety and essential performance.

IEC 60601-1-2: Medical electrical equipment. Part 1-2. General requirements for basic safety and essential performance. Collateral standard. Electromagnetic disturbances.